
## Window and Door Technology



## Roto Patio Inowa | 400

Intelligent hardware for tightly sealed sliding systems

Installation, maintenance and operation instructions for timber and PVC profiles up to 400 kg



## **Contact**

### **Roto Frank**

Fenster- und Türtechnologie GmbH

Wilhelm-Frank-Platz 1 70771 Leinfelden-Echterdingen Germany Phone +49 711 7598 0 Fax +49 711 7598 253 info@roto-frank.com www.roto-frank.com





Ī	1	General information	9
	1.1	Version history	Ç
	1.2	Instructions	C
	1.3	Symbols	10
	1.4	Pictographs	10
	1.5	Product features	11
	1.6	Abbreviations	13
	1.7	Target groups	13
	1.8	Target groups' obligation to give instructions	14
	1.9	Copyright protection	15
	1.10	Limitation of liability	15
	1.11	Preserving the surface finish	
$\wedge$	2	Security	
<u> </u>	2.1	Presentation and structure of warning instructions	17
	2.2	Security levels of warning instructions	17
	2.3	Stipulated use	17
	2.3.1	Misuse	18
	2.3.2	Usage restriction	18
	2.4	Stipulated use for end users	18
	2.4.1	Misuse	19
	2.5	Basic safety information	19
	2.5.1	Installation	19
	2.5.2	Use	20
	2.5.3	Ambient conditions	21
	2.6	Operation	21
15	3	Information on the product	23
H	3.1	General hardware characteristics	23
	3.2	Application ranges	23
	3.3	Application diagrams	24
	3.3.1	C dimension	24
	3.3.2	400 kg	25
	3.4	Design variants	27



	3.4.1	Overview	27
	3.5	Hardware groove dimensions	27
	3.6	Dimensions of the roller track	28
	3.7	Dimensions of the tilt protection device	28
	3.8	Component dimensions	
	4	Hardware overviews	
	4.1	Timber	34
	4.1.1	Diagram A, K	34
	4.1.2	Diagram A', K'	38
	4.1.3	Diagram C	42
	4.1.4	Diagram C'	48
	4.2	PVC	54
	4.2.1	Diagram A, K	54
	4.2.2	Diagram A', K'	58
	4.2.3	Diagram A, K   RC 2 / RC 2 N	62
	4.2.4	Diagram C	66
	4.2.5	Diagram C'	72
	5	Espagnolettes	77
	5.1	T&T espagnolettes	77
	5.1.1	Backset 25, 30, 35, 40, 50 mm	77
ñ	6	Jigs / tools	79
[M]	6.1	Drilling jigs	79
	6.1.1	Roller unit / control unit	79
	6.1.2	Centre closer	79
	6.1.3	Strikers	80
	6.1.4	Marker	81
	6.1.5	Tilt protection device	81
	6.2	Tools	81
	6.2.1	Hex key	81
	6.2.2	Adjustment tools	82
	6.2.3	Extractor handle	82
	6.2.4	Tensioning tool	83

	6.3	Punches	83
	6.3.1	Pneumatic punch – PS 100	83
	6.3.2	Hydropneumatic punch – DUO	84
<b>-</b>	7	Accessories	85
Image: section of the latest depth of the latest dep	7.1	Control unit set with Soft function	85
	7.2	Activator spare part for control unit with soft function	86
	7.3	Rubber buffer	87
	7.4	Label	87
	8	Brief instructions	89
	8.1	Diagram A, A', K, K'	
11	9	Installation	
3	9.1	Processing instructions	90
	9.2	Screw connections	91
	9.2.1	Overview	92
	9.3	Drilling and routing dimensions	93
	9.3.1	VT espagnolette	93
	9.3.2	VT espagnolette, lockable	94
	9.3.3	External recessed grip	94
	9.3.4	Operating sequence control cam	95
	9.3.5	Striker H, can be routed in	95
	9.3.6	Rubber buffer	96
	9.3.7	Tilt protection device	96
	9.4	Sash	97
	9.4.1	Force-fit connection	97
	9.4.2	Cropping the hardware components	98
	9.4.3	Installation sequence	99
	9.4.3.1	Diagram A	99
	9.4.4	Corner drive	100
	9.4.5	Centre locks	100
	9.4.5.1	Centre lock, vertical	100
	9.4.5.2	Centre lock, horizontal	101
	9.4.6	VT espagnolette	101



9.4.7	Handle and recessed grip	102
9.4.8	Roller unit	103
9.4.9	Stabilisation unit	105
9.4.10	Control unit	107
9.4.11	Centre closer	109
9.4.12	Centre closer for anti-pushback function.	111
9.4.13	Rubber buffer	113
9.4.14	Diagram C / C' – faceplate component positions	114
9.4.15	Striker, diagram C	116
9.4.15.1	Drilling the holes for striker, diagram C	116
9.4.15.2	Installing the diagram C striker	116
9.4.16	Installing the buffer	117
9.4.17	Operating sequence control	118
9.5	Frame	120
9.5.1	Striker positions	120
9.5.2	Striker, screw-on	125
9.5.2.1	Preparing the frame for the striker, screw-on	125
9.5.2.2	Drilling the holes for the striker	127
9.5.2.3	Installing the striker	128
9.5.3	Striker to prevent incorrect operation	129
9.5.3.1	Drilling the holes for the striker to prevent incorrect operation	129
9.5.3.2	Installing the striker to prevent incorrect operation	130
9.5.4	Buffer	131
9.5.4.1	Drilling the holes for the buffer	131
9.5.4.2	Installing the buffer	132
9.5.5	Striker for anti-pushback function	133
9.5.6	Roller track	134
9.5.7	Guide track	136
9.5.8	Rubber buffer	137
9.6	Joining the sash and frame	137
9.6.1	Inserting the sash	138
9.6.2	MUL striker	142
9.6.2.1	Drilling the holes for the MUL striker	142

	9.6.2.2	Installing the MUL striker	143
	9.6.3	SEC MUL striker	144
	9.6.3.1	Drilling the holes for the MUL striker	144
	9.6.3.2	Installing the SEC MUL striker	145
	9.6.4	Activator and packer	145
	9.6.4.1	Determining the quantity of packers	145
	9.6.4.2	Diagram A	146
	9.6.4.3	Diagram C	147
	9.6.5	Tensioning the control unit with soft function	148
	9.6.6	Tilt protection device	149
	9.6.7	End stop with packer	151
	9.6.8	Guide track stopper	152
	9.6.9	Notes on final assembly	
	10	Installation drawings	
4	10.1	Explanation	154
	10.2	Diagram A, K, A', K'	155
	10.3	Diagram A, K   RC 2 / RC 2 N   PVC	156
	10.4	Diagram C, C'	
*	11	Adjustment	
	11.1	Striker	158
	11.2	MUL locking cam / pin for anti-pushback function – adjustable	158
	11.3	Roller unit	159
<b>Pin</b>	12	Operation	160
4	12.1	Operating information	160
	12.1.1	Roto Patio Inowa	160
	12.2	Fault assistance	160
<u> </u>	13	Maintenance	161
	13.1	Maintenance intervals	161
	13.2	Cleaning	162
	13.3	Care	162
	13.3.1	Roto Patio Inowa	163



	13.4	Performance test	163
	13.5	Repair	164
4	14	Dismantling	165
5	14.1	Unhinging the sash	165
	14.2	Hardware components	167
	15	Transport	168
	15.1	Transporting elements and hardware	168
	15.2	Storing the hardware	169
<b>*</b>	16	Disposal	170
55	16.1	Disposing of packaging	170
	16.2	Disposing of hardware	170

### 1 General information

### 1.1 Version history

Version	Date	Changes
v0	21/09/2021	
v1	23/05/2022	Figure amended → from page 24 → from page 28.

### 1.2 Instructions

This manual contains important information, instructions, application diagrams (max. sash sizes and weights) and assembly instructions for the installation, maintenance and operation of hardware.

The information and instructions contained in this document refer to products belonging to the Roto hardware system named on the front page.

All steps must be completed in sequence.

The following documents apply in addition to these instructions:

Handles catalogue: CTL\_1

The following guidelines also apply:

#### Gütegemeinschaft Schlösser und Beschläge e.V.

- Directive TBDK: Attachment of supporting fitting components for turnonly and tilt&turn fittings
- Directive VHBE: Hardware for windows and balcony doors Guidelines/ advice for end-users
- Directive VHBH: Hardware for windows and balcony doors Guidelines/ advice on the product and on liability

### VFF (German Window and Facade Association)

- TLE.01: Correct handling of ready-to-install windows and external doors during transport, storage and installation
- WP.01: Maintenance of windows, facades and external doors Maintenance, care and inspection Information for sales
- WP.02: Maintenance of windows, facades and external doors Maintenance, care and inspection Measures and documents
- WP.03: Maintenance of windows, facades and external doors Maintenance, care and inspection Maintenance agreement

### Additional guidelines

- Instructions and information issued by profile manufacturers, e.g. manufacturers of windows and balcony doors
- Instructions and information issued by screw manufacturers
- The applicable regulations, directives and national laws

#### Storing the instructions

These instructions are an important part of the product. The instructions must be stored so that they are always to hand.

### **Explanation of the markings**

The manual uses the following markings for emphasis (e.g. in figures or instructions):

Subject to change. Roto Patio Inowa | 400 IMO\_559\_EN\_v1 · 05 / 2022 · **9** 



Marking	Meaning
	Sash
	Frame
	Drill holes, routing or screw positions
	Unaffected components / indirectly affected components
	Components, arrows or movements that have just been described
1	Item number
[1]	Legend
[A]	Steps



### **INFO**

Any dimensions without a unit in the instructions are given in millimetres (mm). Other units of measurement are clearly indicated by the presence of the differing unit.




### **INFO**

Figures are provided in the left-hand version. The process for the right-hand version is mirror-inverted.

## 1.3 Symbols

Symbol	Meaning
•	First-level list
	Second-level list
$\rightarrow$	(Cross-)reference
$\triangleright$	Result
<b>&gt;</b>	Unnumbered step
1.	Numbered step
a.	Numbered second-level step
⇒	Requirement

## 1.4 Pictographs






Symbol	Meaning
	Moving the handle position vertically upwards to the open sliding position
	Moving the handle position vertically downwards to the closed position
	Closed position
	Sash handle height (centre-left)
	Left of sash
	Top of sash
	Top right and bottom right of sash
	Top and bottom of sash
	Top left and right and bottom left and right of sash
	Right of sash
	Bottom of sash
2 1	Sash diagram C, position of operating sequence control – timber
2 1	Sash diagram C, position of operating sequence control – PVC
2 1	Sash diagram C, second opening sash, right
	Left of frame
	Bottom left of frame
	Top left of frame
	Top right of frame
	Bottom of frame

## 1.5 Product features

Symbol	Meaning
	Order quantity
	Description





Symbol	Meaning
	Width
[*]	Call-out
•••	Backset
	Installation DIN left / right
	Colour
Roto	Colour code, Roto
l <b>←→</b> I	Sash width
<b>₫</b>	Sash height
3	Sash weight
	Fixed handle height
1	Height
i	Information
	Coupling dimension
	Couplable
-	Length
	Material
Nο	Material number
J. J.	Installation type
<b>*</b>	Position

**12** · 05 / 2022 · IMO\_559\_EN\_v1



Symbol	Meaning
<b>©</b> #	Number of locking cams
0	Type of locking cams
#	Piece(s)

### 1.6 Abbreviations

Abbreviation	Meaning
approx.	approximately
CTL	Catalogue
DIN L	DIN left
DIN R	DIN right
BS	Backset
Е	E cam
IMO	Installation instructions
SRW	Sash rebate width
SRH	Sash rebate height
S.kg	Sash weight
K	K cam
KU	Couplable
kg	Kilograms
KSR	Vertical tilting
L	Length
Max.	Maximum
MUL	Mullion
Min.	At least
mm	Millimetres
CL	Centre lock
Nm	Newton metres
Not sh.	Not shown
FIW	Frame internal width
Pc. / pcs	Piece(s)
WAF	Key size
V	V cam
e.g.	For example

## 1.7 Target groups

The information in this document is directed at the following target groups:

#### Hardware dealers

The "hardware dealers" target group includes all companies and individuals that purchase hardware from hardware manufacturers for resale, without modifying or further processing the hardware.

### Window and balcony door manufacturers

The "window and balcony door manufacturers" target group includes all companies and individuals that purchase hardware from hardware manufacturers or hardware dealers and further process the hardware by integrating it in windows and balcony doors.

 Subject to change.
 Roto Patio Inowa | 400
 IMO\_559\_EN\_v1 · 05 / 2022 · 13



### Building element dealers or installation companies

The "building element dealers or installation companies" target group includes all companies and individuals that purchase windows and balcony doors from window and balcony door manufacturers for resale and for installation in construction projects, without modifying the windows or balcony doors.

### **Builders**

The "builders" target group includes all companies and individuals who place orders for the manufacture of windows and balcony doors for installation in their construction projects.

#### **End users**

The "end users" target group includes all individuals who use the installed windows and balcony doors.

### 1.8 Target groups' obligation to give instructions



#### **INFO**

Each target group must fulfil their obligation to give instructions in full.

Unless specified otherwise in the text below, documents and information can be passed on as a printed document, on a data storage device or via the Internet.

#### Responsibility of hardware dealers

Hardware dealers must pass the following documents on to the window and balcony door manufacturer:

- Catalogue
- Installation, maintenance and operation instructions
- Directive on attachment of supporting fitting components for turn-only and tilt&turn fittings (TBDK)
- Guidelines/advice on the product and on liability (VHBH)
- Guidelines/advice for end-users (VHBE)

### Responsibility of the window and balcony door manufacturer

The window and balcony door manufacturer must pass the following documents on to building element dealers or the builder, even if a subcontractor (installation company) is involved:

- Installation, maintenance and operation instructions
- Directive on attachment of supporting fitting components for turn-only and tilt&turn fittings (TBDK)
- Guidelines/advice on the product and on liability (VHBH)
- Guidelines/advice for end-users (VHBE)

They must ensure that the end users are provided with the documents and information intended for them in printed format.

## Responsibility of building element dealers and the installation company

Building element dealers must pass the following documents on to the builder, even if a subcontractor (installation company) is involved:



- Installation, maintenance and operation instructions (with a focus on hardware)
- Guidelines/advice on the product and on liability (VHBH)
- Guidelines/advice for end-users (VHBE)

### Responsibility of the builder

The builder must pass the following documents on to the end user:

- Installation, maintenance and operation instructions (with a focus on hardware)
- Guidelines/advice for end-users (VHBE)

## 1.9 Copyright protection

The contents of this document are copyright-protected. This content can be used when working with the hardware. Any other use is not permitted without written permission of the manufacturer.

### 1.10 Limitation of liability

All information and instructions contained in this document have been compiled in consideration of the applicable standards and regulations, the latest developments in technology and many years of knowledge and experience.

The hardware manufacturer assumes no liability for damage caused by:

- Failure to comply with this document and all product-specific documents and other applicable directives (see the chapters entitled "Security" and "Stipulated use").
- Improper use / misuse (see the chapters entitled "Security" and "Stipulated use").
- Insufficient invitation to tender, non-compliance with installation specifications and non-compliance with the application diagrams (where available).
- Increased contamination.

Claims made by third parties against the hardware manufacturer on account of damage resulting from misuse or failure to comply with the obligation to give instructions on the part of hardware dealers, window, door and balcony door manufacturers and building element dealers or the builder are passed on accordingly.

The obligations agreed in the delivery contract, the general terms and conditions, the hardware manufacturer's terms and conditions of delivery and the legal provisions applicable when the contract was concluded shall apply.

The warranty only covers original Roto components.

We reserve the right to make technical changes as part of improvement to performance characteristics and further development.

Subject to change. Roto Patio Inowa | 400 IMO\_559\_EN\_v1 · 05 / 2022 · **15** 

## 1.11 Preserving the surface finish



### **ATTENTION**

### Surface treatments may cause property damage.

Surface treatments (e.g. painting and varnishing) on elements can damage components or prevent them from working properly.

- ► For masking, only use adhesive tape that does not damage the paint coats. Consult the manufacturer if in doubt.
- Protect components against direct contact with the surface treatment.
- Protect components against contamination.



#### ATTENTION

## Using incorrect cleaning agents and sealing compounds may cause property damage.

Cleaning agents and sealing compounds may damage the surfaces of components and gaskets.

- Do not use aggressive or flammable liquids, acidic cleaners or abrasive cleaners.
- Only use mild, pH-neutral cleaning agents that have been diluted.
- Apply a thin protective film to the components, for example using a cloth soaked in oil.
- Avoid aggressive vapours (e.g. produced by formic acid, acetic acid, ammonia, amine compounds, ammonia compounds, aldehyde, carbolic acid, chlorine, tannic acid) around the element.
- Do not use any acetic acid-crosslinking or acid-crosslinking sealing compounds or those with the aforementioned constituents as both direct contact with the sealing compound and its fumes can corrode the surface of the components.



### **ATTENTION**

### Contamination may cause property damage.

Contamination prevents components working properly.

- Remove deposits and contamination caused by construction materials (e.g. plaster, gypsum).
- ▶ Keep components free of deposits and contaminants.



### **ATTENTION**

## (Permanently) damp room air may cause property damage.

Damp room air can lead to mould growth and corrosion caused by condensation.

- Provide adequate ventilation for components, particularly during the construction phase.
- Intensively air out the room several times per day by opening all elements for approximately 15 minutes. If intensive airing is not an option, place the elements in the tilt position and provide airtight masking inside the room, e.g. if there is fresh screed that cannot be walked on or must not be exposed to draughts. Discharge any humidity present in the room air to the outside using condensation dryers.
- Establish a ventilation plan for more complex construction projects if necessary.
- Provide adequate ventilation during holiday periods as well.



## 2 Security

This manual contains instructions relating to safety. The principal safety information in this chapter includes information and instructions relevant to the safe use or maintaining the safe condition of the product. Warning instructions that relate to handling warn of residual risks and are located before steps that are relevant to safety.

Follow all of the instructions in order to prevent personal injury and property and environmental damage.

### 2.1 Presentation and structure of warning instructions

The warning instructions relate to individual actions and are structured as follows with a warning symbol:



### **DANGER**

### Nature and source of the danger.

Explanation and description of the danger and the implications.

Measures to take to avert the danger.

## 2.2 Security levels of warning instructions

The warning instructions that relate to handling are identified differently according to the severity of the associated danger. The signal words and the associated warning symbols used are clarified below.



#### **DANGER**

### Immediate risk of death or serious injuries.

▶ Observe these warning instructions to avoid personal injuries.



### WARNING

### Potential risk of death or serious injuries.

Observe these warning instructions to avoid personal injuries.



### **CAUTION**

#### Risk of injuries

Observe these warning instructions to avoid personal injuries.



### **ATTENTION**

## Reference to property or environmental damage.

Observe these warning instructions to avoid property or environmental damage.

## 2.3 Stipulated use

The hardware system described in these instructions is intended for installation in sliding sashes in windows and balcony doors. The hardware system is only intended for further processing on windows and balcony door sashes for vertical installation made from the materials described in these instructions. The hardware system opens sashes in windows and balcony doors and closes them tightly.

Stipulated use also includes compliance with all safety information and specifications contained in these instructions, the other applicable documents and the applicable regulations, directives and national laws.

Subject to change. Roto Patio Inowa | 400 IMO\_559\_EN\_v1 · 05 / 2022 · 17



### 2.3.1 Misuse

Any use and processing of the products that goes beyond or differs from the stipulated use is considered misuse and can lead to hazardous situations.



### **WARNING**

### Misuse may pose a risk of death!

Misuse and incorrect installation of hardware can lead to serious injuries.

- Only use hardware combinations that have been approved by the hardware manufacturer.
- Only use original accessories or those that have been approved by the hardware manufacturer.
- Note the product-related documentation → from page 9.

### 2.3.2 Usage restriction

Opened sashes in windows and balcony doors, and windows and balcony door sashes that are unlocked or placed in ventilation positions, only have a shielding effect. They do not meet the following requirements:

- Joint sealing
- Driving rain impermeability
- Sound insulation
- Thermal insulation
- Burglary inhibition

## 2.4 Stipulated use for end users

On windows or balcony doors with sliding hardware, window sashes or balcony door sashes can be moved horizontally or vertically by operating a handle.

On special structures, various sashes can additionally be brought into a turn position and / or into a tilt position restricted by the scissor stay version.

When closing a sash and locking the hardware, the gasket counter force must generally be overcome.



### **WARNING**

## Opening and closing sashes in an uncontrolled manner may pose a risk of death!

Opening and closing the sash in an uncontrolled manner may lead to serious injuries.

- ► Ensure that the sash does not collide with the frame, opening restrictor (buffer) or other sashes when it is moved into the fully open or closed position.
- ▶ Ensure that the sash is slowly guided by hand throughout its entire movement range, until it has been brought into a fully closed or opening position.





### **ATTENTION**

## Opening and closing sashes in an uncontrolled manner may result in property damage.

Opening and closing the sash in an uncontrolled manner may cause the element to malfunction.

- Ensure that the sash does not collide with the frame, opening restrictor (buffer) or other sashes when it is moved into the fully open or closed position.
- ► Ensure that the sash is slowly guided by hand throughout its entire movement range, until it has been brought into a fully closed or opening position.

Any use and processing of the products that goes beyond or differs from the stipulated use is considered misuse and can lead to hazardous situations.

No claims can be made on account of damage resulting from failure to comply with the stipulated use.

#### 2.4.1 Misuse

Any use and processing of the products that goes beyond or differs from the stipulated use is considered misuse and can lead to hazardous situations.



### **WARNING**

### Misuse may pose a risk of death!

Misuse and incorrect installation of hardware can lead to serious injuries.

- Only use hardware combinations that have been approved by the hardware manufacturer.
- Only use original accessories or those that have been approved by the hardware manufacturer.
- Note the product-related documentation → from page 9.

### 2.5 Basic safety information

The following hazards may arise when handling the product:

## 2.5.1 Installation

## Incorrect installation poses an immediate risk of death or serious injuries.

Incorrect installation or assembly of hardware can lead to hazardous situations or property damage. Depending on the height of the fall, this can result in serious to life-threatening injuries and glass breakage.

- Only use hardware combinations that have been approved by the hardware manufacturer.
- Only use original accessories or those that have been approved by the hardware manufacturer.
- Always have installation performed by a specialist company.

### Heavy loads pose a risk of injury.

Lifting and carrying heavy loads may lead to injuries in the event of a fall or physical overexertion.

▶ Note the applicable accident prevention regulations.



Transport heavy loads with two people and use suitable transportation means (such as an industrial truck).

### Physical strain may cause damage to health.

Moving heavy loads for extended periods leads to physical injury in the long term.

- When carrying and lifting by hand, comply with a maximum weight of 25 kg for men and 10 kg for women.
- Carry and lift even small loads with an ergonomically correct posture.

### 2.5.2 Use

## Falls from open windows and balcony doors present an immediate risk of death and pose the risk of serious injuries.

Opened sashes of windows and balcony doors create a danger zone. Depending on the height of the fall, this can result in serious to life-threatening injuries and glass breakage.

- ▶ Take care when in the vicinity of open windows and balcony doors.
- Keep children and anyone unable to understand the risks away from the hazardous area.

## Trapping body parts in the opening between sash and frame may lead to serious injuries.

Gripping between the sash and frame when closing windows and balcony doors poses the risk of crushing injuries.

- ▶ When closing windows and balcony doors, never grip between the sash and frame and always exercise caution.
- Keep children and anyone unable to understand the risks away from the hazardous area.

## Opening and closing sashes improperly poses the risk of injury and property damage.

Incorrect opening and closing of sashes can result in serious injuries and substantial property damage.

- ▶ When moving the sash, ensure that it will not slam against the frame or other sashes once fully opened or closed.
- Ensure that the sash is slowly guided by hand throughout its entire movement range, until it has been brought into a fully closed or opening position.
- When closing a sash and locking the hardware, the gasket counter force must be overcome.

### Misuse poses a risk of injury and property damage.

Misuse can lead to hazardous situations and may destroy the hardware, frame materials or other individual components within the windows or balcony doors.

- Do not introduce any obstacles in the opening area between the frame and window or balcony door sashes.
- Do not place additional loads on windows and balcony door sashes.



Refrain from intentionally or uncontrollably slamming or pushing the window or balcony door sash against the window reveal.

## Improper maintenance poses the potential risk of injury and property damage.

Windows and balcony doors, including the hardware, require expert maintenance (care, cleaning, maintenance and inspection) in order to guarantee their proper condition and safe use.

- ▶ Keep the hardware free of deposits and contaminants.
- Carry out care and cleaning tasks as specified in these instructions.
- Always have regular maintenance, adjustment and repair work carried out by a specialist company.

### 2.5.3 Ambient conditions

### Physical and chemical influences may result in property damage.

Hardware components can be permanently damaged to the point that they can no longer function in a saline, aggressive or corrosive environment.

- Do not use the hardware components in a saline, aggressive or corrosive environment.
- Carry out care and cleaning tasks as specified in these instructions.
- Corrosion protection must be inspected by an authorised specialist company as part of regular maintenance work.

#### Moisture may cause property damage.

Depending on the outside temperature, relative humidity of the room air and installation conditions for the windows and balcony doors, a temporary build-up of condensation may occur. This can lead to corrosion on the hardware and mould growth on the frame or wall. Ambient conditions that are too damp, particularly during the construction phase, can lead to timber elements warping.

- Avoid preventing the circulation of air (e.g. due to deep reveals, curtains and unfavourable positioning of heaters or the like).
- Intensively air out the room several times per day.
  Open all windows and balcony doors for approximately 15 minutes so that the air in the room can be completely replaced.
- Provide adequate ventilation during holiday periods as well.
- Create a ventilation plan for construction projects if necessary.

### 2.6 Operation


The safety symbols and markings and the associated warning instructions explained below apply to the safe operation of windows and balcony doors.

### Safety symbols and markings











## 3 Information on the product

### 3.1 General hardware characteristics

- Concealed hardware
- Innovative closing movement perpendicular to the frame profile
- Circumferential gasket
- Even heavy sashes can be opened with less effort because the handle is easy to use.
- Active locking points including in the mullion.
- PVC RC 2 / RC 2 N: SKG\*\*-certified
- Control unit with Soft function:
  - □ SoftClose (damped closing)
  - □ SoftOpen (damped opening)
  - □ SoftStop on the espagnolette side (damped in the locking direction)
  - □ SoftStop on the mullion side (damped in the opening direction)


## 3.2 Application ranges

- The sash runs within the frame profile with a retracting distance of 8 mm.
- Narrow profile views possible
- SRW 1500 mm 3000 mm
- SRH 2000 mm 3600 mm
- S.kg from 150 kg up to max. 400 kg
- Opening diagrams:
  - A and A' (running inward or outward)
  - K and K' (running inward or outward)
  - C and C' (running inward or outward)
- Resistance class basic security and RC 2 / RC 2 N
- Operating range: -20 °C to +80 °C

Subject to change. Roto Patio Inowa | 400 IMO\_559\_EN\_v1 · 05 / 2022 · 23

## 3.3 Application diagrams

## 3.3.1 C dimension



- [1] C dimension
- [2] Glass centre of mass




## INFO

Applicable for C dimensions < 25 mm. Different dimensions must be technically tested by Roto.



### 3.3.2 400 kg

### SRH:SRW = max. 2:1



= Impermissible application range  $\leq 35 \text{ kg/m}^2$   $\leq 50 \text{ kg/m}^2$   $\leq 70 \text{ kg/m}^2$   $\leq 80 \text{ kg/m}^2$ 

The specifications in the application diagram refer to the glass weight in kg/m<sup>2</sup>.

1 mm/m $^2$  glass thickness  $\stackrel{\circ}{=}$  2.5 kg

		Application range
	Sash rebate width	1500 – 3000 mm
I <b>←→</b> I	(SRW)	
<b>T</b>	Sash rebate height	2000 – 3600 mm
₹	(SRH)	
•	Sash weight	Max. 400 kg
	(S.kg)	
_	Glass weight	Max. 80 kg/m <sup>2</sup>

### SRH:SRW = > 2:1 up to max. 3:1

For diagrams A, A', K and K'. Diagrams C and C' available upon request.




### **DANGER**

### The uncontrolled tilting of sashes with aspect ratios > 2:1 poses a risk of death!

Uncontrolled tilting may cause sashes with aspect ratios > 2:1 to jump out of the guide track. This many lead to hazardous situations and cause serious or fatal accidents.

- ▶ The roller track must have two walls → 3.6 "Dimensions of the roller track" from page 28.
- Install the tilt protection device (only without control unit with Soft function) → 3.7 "Dimensions of the tilt protection device" from page 28.





The specifications in the application diagram refer to the glass weight in kg/m<sup>2</sup>.

1 mm/m<sup>2</sup> glass thickness = 2.5 kg



## INFO

The use of control units with Soft function is not possible with aspect ratios > 2:1.


		Application range
	Sash rebate width	1500 – 3000 mm
I <b>←→</b> I	(SRW)	
Ā	Sash rebate height	2000 – 3600 mm
<b>▼</b>	(SRH)	
•	Sash weight	Max. 400 kg
	(S.kg)	
-	Glass weight	Max. 80 kg/m <sup>2</sup>




## 3.4 Design variants

### 3.4.1 Overview


### Diagram A




### Diagram C



### Diagram K




## 3.5 Hardware groove dimensions



Sash profile cross section

- [1] Hardware axis
- [2] Hardware groove



X = SRW (including assembly profile [3])


Y = SRH

### 3.6 Dimensions of the roller track




### **INFO**

Roller track only made from stainless steel or anodised aluminium.



Roller track shape

## 3.7 Dimensions of the tilt protection device




Two walls [1] next to the roller track are required for aspect ratios > 2:1.

## 3.8 Component dimensions













Rubber buffer		Description
		Size 16.5
		Size 17.5
16.5	17.5	

Subject to change. Roto Patio Inowa | 400  $IMO\_559\_EN\_v1 \cdot 05 / 2022 \cdot \textbf{29}$ 

MUL locking cam	Description
	Adjustable
	L = 25 - 53.5

Pin for anti-pushback function	Description
	Adjustable
	L = 25 - 53.5



 Subject to change.
 Roto Patio Inowa | 400
 IMO\_559\_EN\_v1 · 05 / 2022 · 31
 Roto

### 4 Hardware overviews

The hardware overviews on the following pages are a recommendation on the part of Roto Frank Fenster- und Türtechnologie GmbH.

The basic page layout in the hardware overviews chapter firstly shows examples of the combination of individual hardware components, and the associated parts list can be seen on the following pages.

The item numbers in the squares link the hardware overview to the parts list.

The actual composition of the hardware depends on:

- the height of the element
- the width of the element
- the weight of the element
- Profile system
- Design variant



## INFO Profile properties

Design the profile optimally for the corresponding weights. Proper load transfer must be ensured by the profile manufacturer / fabricator.

Ensure that the rollers on the roller track run smoothly. Keep the roller track clean, do not powder coat or paint it.

The currently valid Roto profile assessment drawing for the specific profile and the applicable documents described in said drawing must be observed.

Please request these details from your responsible Roto sales representative.

Recommended handles can be found in the handles catalogue.

Determine the quantity of required hardware components with Roto Con Orders.



### INFO Roto Con Orders

Efficient online hardware configurator for the custom configuration of individual window and door hardware components. All conventional shapes and opening types can be automatically configured quickly and easily. Individual parts lists, including application ranges and an exemplary hardware overview, can be ordered from your responsible sales representative.



www.roto-frank.com






 Subject to change.
 Roto Patio Inowa | 400
 IMO\_559\_EN\_v1 · 05 / 2022 · 33
 Roto

### 4.1 Timber

## 4.1.1 Diagram A, K





### **Application range**

**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a] [1b]	Corner drive	With E cam With V cam	
<b>8</b> <sup>#</sup>		8	No
1		Е	260275
1		V	260272



[4]	Espagnolette	extension	, SRH > 2000	) mm
		<b>8</b> *	9	Nº
200	Υ	-	-	308267
400	Υ	_	-	297858
600	Υ	1	V	337711

### Size-specific combinations:

<b>‡</b>		<b>8</b> *	0	Nο
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	_	-	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	_	-	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	_	-	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	_	-	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

### Centre lock (CL)

[5]	CL component	t, horizont	al	
		<b>9</b> <sup>#</sup>	8	No
200	Υ	-	-	308267
400	Υ	-	_	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

### Size-specific combinations:

←→	-	14	8	9	Nō
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362

←→	-	1-	<b>8</b> *	8	Nο
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6] C	L compone	<b>ent 130</b> , hori	zontal and v	ertical 📜 6
-		<b>8</b> *	9	Nº
130	Υ	1	K	862364


[7]	CL component,	vertica	l, on the mullion	
	-	<b>9</b> **	8	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	K	862366

### Size-specific combinations:

<b>‡</b>	-	8	9	No
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	_	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	-		297858
	600 KU	1	K	862366
	200 KU	-	_	308267
	600 KU	1	K	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	_	297858
	600 KU	1	K	862366
3401 – 3600	600 KU	1	K	862366
	400 KU	-	_	297858
	600 KU	1	K	862366
	600 KU	1	K	862366

[9]	Roller unit	₩ 2
		Nº
41	Left	862367
	Right	862368





[10]	<b>Control unit</b> , on the mullion side and in the centre → from page 85	7∓ 1-3
	Alternatively (on the mullion side):	
	Control unit set with Soft function (incl. activator) → from page 85	₩ 1
	8.0	1.10

		No
41	Left	862371
	Right	862372

[*]	Control unit set with Soft function, on the espagnolette side → from page 85	`₩ 1
	Alternatively:	
[10]	Control unit	
[10]	Control unit	

Conter	nts:	
[*]		#
[29]	Activator	1
[30]	Control unit with Soft function	1

[11] Centre clos	er, adjustable	
		Nº
41	Left	862395
	Right	862396
<u></u>		0.0
≤ 2400		3
2401 – 3400		4
> 3400		5

[12] MUL locking cam, adjustable		
*		Nο
Gasket compression adjustable	25	895955
	26	895966
	27	895970
	32	786728
	35.5	858628
	36	895972
	39.5	839047
	42	861550
	44	895973
	45.8	791838
	47.8	788696
	49	895974

*	-	Nº
	53.5	839045
<u>↑</u>		<b>\</b>
≤ 2400		3
2401 – 3400		4
> 3400		5

[15] Striker to prevent incorrect operation	# 1
-	Nº
Striker to prevent incorrect operation	822789
[16] Handle (200 mm handle length) → CTL_1	7₩ 1

Recessed grip CTL_1	) (43 mm distance), not si	h. → 및 1
[17] Striker		
T T	8:8	Nº
Screw-on	-	744579
Can be routed in	Left	798224

	Right	798245
<b>*</b>		
≤ 2800		3
2801 – 3400		4
> 3400		5

[18] Buffer	<b>\_</b> 2
	No
14	635307


[20] MUL striker	
	Nº
Screw-on	793493
Can be routed in	798223
<b>‡</b>	
≤ 2400	3
2401 – 3400	4
> 3400	5

# [21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.

Roto		Nō
R01.1	Natural silver	819632
R05.3	Medium bronze	819631
R06.2	Jet black	798979
R07.2	Traffic white	808054
<u>‡</u>		
≤ 2400		3
≤ 2400 2401 – 3400		3
		-

[31] E	nd stop,	profile-related	
--------	----------	-----------------	--






#### **Optional**



[1] Only use the number of packers that is specified in the profile assessment.



## 4.1.2 Diagram A', K'





**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a] [1b]	Corner drive	With E cam With V cam	
<b>8</b> <sup>#</sup>		8	No
1		Е	260275
1		V	260272



[4]	Espagnolette	extension	, SRH > 2000	) mm
		<b>8</b> *	9	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	V	337711

## Size-specific combinations:

<u>‡</u>		<b>9</b> **	9	Nº
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	_	_	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	_	_	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	_	_	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	_	_	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

## Centre lock (CL)

[5]	CL component	, horizont	al	
		<b>9</b> <sup>#</sup>	8	No
200	Υ	-	-	308267
400	Υ	-	_	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

#### Size-specific combinations:

←→		1.	8	8	No
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362

←→	-		<b>8</b> *	<u>©</u>	Nº
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6] C	L compone	<b>ent 130</b> , hori	zontal and v	ertical 📜 6
-		<b>8</b> *	9	Nº
130	Υ	1	K	862364

[7]	CL component,	vertica	l, on the mullion	
	-	<b>9</b> **	8	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	K	862366

#### Size-specific combinations:

		8	0	Nο
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	-	-	297858
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366
3401 – 3600	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366
	600 KU	1	K	862366

[8] F	Roller track	₩ 1
-		Nº
3200		807733
6400		807734

[9]	Roller unit	₹2
		Nº
41	Left	862367
	Right	862368



#### **INFO**

[90] Stabilisation unit

DIN L: order right components.

DIN R: order left components.

[90] Stabilisa	tion unit	
		Nº
41	Left	891368
	Right	891369
l←→I		
≤ 2110		1
> 2110		2



#### INFO

DIN L: order right components.

DIN R: order left components.






#### **INFO**

DIN L: order right components.

Right

DIN R: order left components.



[11] Centre	closer, adjustable	
		Nº
41	Left	862395
	Right	862396
<u>₹</u>		-
≤ 2400		3
2401 – 3400		4
> 3400		5



#### **INFO**

DIN L: order right components.

DIN R: order left components.

[12] MUL locking cam, adjustable		
*	-	Nο
Gasket compression adjustable	25	895955
	26	895966
	27	895970
	32	786728
	35.5	858628
	36	895972
	39.5	839047
	42	861550
	44	895973
	45.8	791838
	47.8	788696
	49	895974
	53.5	839045
<b>∓</b>		••
≤ 2400		3
2401 – 3400		4
> 3400		5



TI

Screw-on

Can be routed in

862372

Nο

744579

798224

Left



Right 798245  2800 3 2801 - 3400 4 2400 5  18] Buffer				
2800 3 2801 - 3400 4 2801 - 3400 5  18] Buffer	Y II			Nº
3 2800			Right	798245
3 2800	<b>4</b>			~
### 1801 - 3400				
18  Buffer				
Nº  14 635307  20] MUL striker  15 Nº  16 Screw-on 793493  17 798223  18 2400 3  18 2400 4  19 3400 5  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  20 Nº  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  20 Nº  210.1 Natural silver 819632  210.2 Jet black 798979  210.2 Traffic white 808054  211 Cover cap for MUL striker, only in combination with MUL striker, screw-on.  212 Nº  213 Nº  21400 819631  2400 919632  31400 919632  315 End stop, profile-related 4  Alternatively:  215 Nº  216 Signal grey 2006569  217 Rubber buffer → from page 87  218 Nº  219 Signal grey 2006569  220 RAL 7004 Signal grey 2006569  231 End stop packer, profile-related  23 Nº  2400 Signal grey 2006569  2400 Signal grey 2007421	> 3400			·
Nº  14 635307  20] MUL striker  15 Nº  16 Screw-on 793493  17 798223  18 2400 3  18 2400 4  19 3400 5  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  20 Nº  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  20 Nº  210.1 Natural silver 819632  210.2 Jet black 798979  210.2 Traffic white 808054  211 Cover cap for MUL striker, only in combination with MUL striker, screw-on.  212 Nº  213 Nº  21400 819631  2400 919632  31400 919632  315 End stop, profile-related 4  Alternatively:  215 Nº  216 Signal grey 2006569  217 Rubber buffer → from page 87  218 Nº  219 Signal grey 2006569  220 RAL 7004 Signal grey 2006569  231 End stop packer, profile-related  23 Nº  2400 Signal grey 2006569  2400 Signal grey 2007421				<b>~</b> .
20] MUL striker    1	_	er		
20] MUL striker  Nº Screw-on Can be routed in 793493 798223  1				No
Nº Screw-on 793493 Can be routed in 798223  1	14			635307
Nº Screw-on 793493 Can be routed in 798223  1	[20] MUL	striker		
Can be routed in 793493 Can be routed in 798223   2400 3 Can be routed in 798223   2400 3 Can be routed in 798223   2401 – 3400 4 Can be routed in 798223   2401 – 3400 5  27				NΙΘ
2400 3 2401 – 3400 4 3400 5  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  201.1 Natural silver 819632 305.3 Medium bronze 819631 306.2 Jet black 798979 307.2 Traffic white 808054  2400 3 2401 – 3400 4 3 3400 5  31] End stop, profile-related  1 Alternatively: 37] Rubber buffer → from page 87  25 Nº 26 End stop RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600  32] End stop packer, profile-related  33 Nº 26 RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600	•			
2400 3 2401 – 3400 4 2401 – 3400 5  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  Nº 201.1 Natural silver 819632 205.3 Medium bronze 819631 206.2 Jet black 798979 207.2 Traffic white 808054  1		d in		
3 2400 3 2401 – 3400 4 2401 – 3400 5  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  23 Nºº 2401.1 Natural silver 819632 2505.3 Medium bronze 819631 2606.2 Jet black 798979 2607.2 Traffic white 808054  2400 3 2401 – 3400 4 2401 – 3400 5  31] End stop, profile-related Alternatively: 37] Rubber buffer → from page 87  25 Nºº 26nd stop RAL 7004 Signal grey 2006569 27 RAL 9005 Jet black 349600  32] End stop packer, profile-related  32 Nºº 28 Nºº 29 RAL 7004 Signal grey 2006569 349600	Jan 20 104101	•		, 00220
2401 – 3400 5  21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  20	<u>‡</u>			
21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  Nº R01.1 Natural silver 819632 R05.3 Medium bronze 819631 R06.2 Jet black 798979 R07.2 Traffic white 808054  1 2 2400 3 R401 – 3400 4 R401 – 3400 5 R106.2 Striker RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600  23 End stop packer, profile-related R106.2 RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600	≤ 2400			3
21] Cover cap for MUL striker, only in combination with MUL striker, screw-on.  Nº  R01.1 Natural silver 819632 R05.3 Medium bronze 819631 R06.2 Jet black 798979 R07.2 Traffic white 808054  1	2401 – 3400			4
with MUL striker, screw-on.  Nº 1001.1 Natural silver 819632 1805.3 Medium bronze 819631 1806.2 Jet black 798979 1807.2 Traffic white 808054  1	> 3400			5
819632 805.3 Medium bronze 819631 806.2 Jet black 798979 807.2 Traffic white 808054   \$\frac{1}{4}\$				ombination
805.3 Medium bronze 819631 806.2 Jet black 798979 807.2 Traffic white 808054   2400 3 2401 – 3400 4 331] End stop, profile-related Alternatively: 37] Rubber buffer → from page 87  End stop RAL 7004 Signal grey RAL 9005 Jet black 349600  32] End stop packer, profile-related RAL 7004 Signal grey 2006569 RAL 7004 Signal grey 2007421	Roto	6		Nº
306.2 Jet black 798979 807.2 Traffic white 808054  2400 3 2401 – 3400 4 331] End stop, profile-related Alternatively: 37] Rubber buffer → from page 87  Alternatively: 37] Rubber buffer → from page 87  RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600  32] End stop packer, profile-related  RAL 7004 Signal grey 2007421	R01.1			
R07.2 Traffic white 808054  2400 3 2401 – 3400 4  331] End stop, profile-related Alternatively:  37] Rubber buffer → from page 87  Alternatively:  Signal grey 2006569 RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600  32] End stop packer, profile-related  RAL 7004 Signal grey 2007421	R05.3		ze	
2400 3 2401 – 3400 4 2401 – 3400 5  31] End stop, profile-related				
3 2400 3 4 4 5 3400 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	107.2	Trainio Willio		000001
401 – 3400 4 5 31] End stop, profile-related	<u>‡</u>			
3400 5  31] End stop, profile-related Alternatively:  37] Rubber buffer → from page 87  Page 1	≤ 2400			3
31] End stop, profile-related  Alternatively:  37] Rubber buffer → from page 87  Page 1	2401 – 3400			•
Alternatively:  37] Rubber buffer → from page 87  Rubber buffer → from page 87  RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600  32] End stop packer, profile-related  RAL 7004 Signal grey 2007421	> 3400			5
37] Rubber buffer → from page 87  Robert Signal grey RAL 7004 Signal grey RAL 9005 Jet black 349600  32] End stop packer, profile-related  RAL 7004 Signal grey 2007421	[31] End	<b>stop</b> , profile-re	elated	`₩1
37] Rubber buffer → from page 87  Robert Signal grey RAL 7004 Signal grey RAL 9005 Jet black 349600  32] End stop packer, profile-related  RAL 7004 Signal grey 2007421				
RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600  32] End stop packer, profile-related  RAL 7004 Signal grey 2007421			om page 87	
End stop RAL 7004 Signal grey 2006569 RAL 9005 Jet black 349600  32] End stop packer, profile-related  RAL 7004 Signal grey 2007421	<b>-</b>		1	Nº
RAL 9005 Jet black 349600  32] End stop packer, profile-related  Nº  RAL 7004 Signal grey 2007421	End stop		Signal grev	
<b>Q</b> Nº Nº RAL 7004 Signal grey 2007421				
<b>Q</b> Nº Nº RAL 7004 Signal grey 2007421	[32] End	stop packe <u>r, </u>	orofile-related	
RAL 7004 Signal grey 2007421				Nº
	`	_		

[37] Rubber buffer → from pag	e 87
	Nº
Stopper	800196
[34] Packer; profile-related quar	ntity <sup>[2]</sup>
	No
Packer	800197

#### **Optional**


[80]		ction device; can only be ontrol unit with Soft function	
<u>†</u>		←⇒	Nº
2000 -	- 3600	1500 – 3000	897049

[2] Only use the number of packers that is specified in the profile assessment.

[33] Stopper, cannot be used in conjunction with a control unit with SoftOpen and SoftStop on the mullion.



## 4.1.3 Diagram C





**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a] (	Corner drive	With E cam	₩6
[1b]		With V cam	₩2
8		<u></u>	Nº
1	Е		260275
1	V		260272





[4]	Espagnolette extension, SRH > 2000 mm					
		<b>8</b> *	8	Nº		
200	Υ	-	-	308267		
400	Υ	-	_	297858		
600	Υ	1	V	337711		

Size-specific combinations:

#### First or second opening sash

₫	-	<b>8</b> **	<u>©</u>	Nο
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	-	-	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	-	-	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	-	-	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	-	-	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

## Centre lock (CL)

[5]	CL componer	<b>nt</b> , horizonta	ıl	
		<b>8</b> *	0	Nº
200	Υ	-	-	308267
400	Υ	_	_	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

Size-specific combinations:

#### First or second opening sash

l <del>≪→</del> l		+	8	9	Nο	
1500 – 1660	1190	1180	1	K	862360	
1661 – 1910	1440	1430	1	K	862361	
1911 – 2110	1440	1430	1	K	862361	
	200	200	_	-	308267	
2111 – 2260	1790	1780	2	K	862362	
2261 – 2460	1790	1780	2	K	862362	
	200	200	-	-	308267	
2461 – 2660	2190	2180	2	K	862363	
2661 – 2860	200	200	-	-	308267	
	2190	2180	2	K	862363	
2861 – 3000	400	400	-	-	297858	
	2190	2180	2	K	862363	

[6]	CL componer	` <b>₩</b> 13		
-		<b>8</b> *	9	No
130	Υ	1	K	862364

[7]	CL componen	<b>t</b> , vertical,	on the mullio	า
-	*****	<b>9</b> *	<u>©</u>	Nº
200	Υ	-	-	308267
400	Υ	-	_	297858
600	Υ	1	K	862366

Size-specific combinations:

#### First opening sash:

<b>‡</b>		8	8	No
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	_	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	-	-	297858
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366



<u>₹</u>	-	8	9	No	Control unit set with Soft function (incl. activator) → from page 85	`₩ 1-
3401 – 3600	600 KU	1	K	862366		NIO
	400 KU	-	-	297858	<b>□</b> 00	Nō
	600 KU	1	K	862366	41 Left	862371
	600 KU	1	K	862366	Right	862372
Second openir	ng sash:				[*] Control unit set with Soft function, or	ı 📜
<u>‡</u>		8	8	No	the espagnolette side → from page 85	
2000 – 2200	200 KU	-	-	308267	Alternatively:	
	600 KU	1	K	862366	[10] Control unit	
2201 – 2400	400 KU	-	-	297858	Contents:	,,
0.404 0000	600 KU	1	K	862366	[*]	#
2401 – 2600	600 KU	1	K	862366	[29] Activator	1
2001 2000	600 KU	1	K	862366	[30] Control unit with Soft function	1
2601 – 2800	600 KU	1	K	862366		
	200 KU	_	_	308267	[11] Centre closer, adjustable	
2001 2000	600 KU 200 KU	1	K	862366		Nº
2801 – 3000		_	-	308267	41 Left	862395
	600 KU	1	K	862366	Right	862396
	200 KU	-	-	308267		
0004	600 KU	1	K	862366	<u> </u>	
3001 – 3200	400 KU	_	_	297858	≤ 2400	6
	600 KU	1	K	862366	2401 – 3400	8
	200 KU	-	-	308267	> 3400	10
	600 KU	1	K	862366		
3201 – 3400	400 KU	-	-	297858	[12] MUL locking cam, adjustable	
	600 KU	1	K	862366	*	No
	400 KU	-	-	297858	Gasket compression adjustable 25	895955
	600 KU	1	K	862366	26	895966
3401 – 3600	600 KU	1	K	862366	27	895970
	400 KU	-	-	297858	32	786728
	600 KU	1	K	862366	35.5	858628
	600 KU	1	K	862366	36	895972
[9] Roller un	si+			7	39.5 42	839047 861550
[9] Roller un				₩ 4	44	895973
				No	45.8	791838
41	Left			862367	47.8	788696
	Right			862368	49	895974
[90] Stabilisa	tion unit				53.5	83904
	0:0			No	<del>*</del> <del>*</del> <del>*</del> •	
41	Left			891368	≤ 2400	6
	Right			891369	2401 – 3400	8
				~	> 3400	10
←→				-	[15] Striker to prevent incorrect operation	Ĵ
≤ 2110				2		Nº
> 2110				4	•	
[10] Control ι	unit, on the m	nullio <u>n și</u>	de a <u>nd in</u>	<b>7.</b> 2-6	Striker to prevent incorrect operation	822789
	e <del>&gt;</del> from pag				[16] Handle (200 mm handle length) → CTL_	1 📜
Alternativ	ely (on the mi	ullion sid	e):			

	ntrol unit set with Soft function ivator) → <i>from page 85</i>	on (incl.	₩ 1-2
	0:0		Nº
41	Left		862371
41	Right		862372
	riigite		002072
the Alt	ntrol unit set with Soft fur e espagnolette side → from pernatively: ntrol unit		1 ₹2
Contents			
[*]			щ
			#
,	Activator		1
[30] C	Control unit with Soft function		1
[11] Ce	ntre closer, adjustable		
-			Nο
41	Left		862395
	Right		862396
₫			-
≤ 2400			6
2401 – 340	0		8
> 3400			10
[12] MU	JL locking cam, adjustable	;	
*			Nº
•			
Gasket con	npression adjustable	25 26	895955 895966
		27	895970
		32	786728
		35.5	858628
		36	895972
		39.5	839047
		42	861550
		44	895973
		45.8	791838
		47.8 49	788696 895974
		53.5	839045
		55.5	000040
<u>‡</u>			••
≤ 2400			6
2401 – 340	00		8
> 3400			10
[15] Str	riker to prevent incorrect o	peration	₹1
			Nō
Striker to p	revent incorrect operation		822789



Nο

862395

862396

₩1

Nο

Nο

828482

828483

809717

819351

Nο

2006569

349600

Nο

2007421

**7** 2

477263

Nο

Nο

Nο

833203

800197

800196

**2** 

810279

#### **Recessed grip** (43 mm distance), not sh. → [25] Centre closer, adjustable, for antipushback function $\Pi$ : $\Pi$ [17] Striker, diagram C 41 Left Nο Right Screw-on 806824 INFO 1 Ä DIN L: order right components. ≤ 2800 3 DIN R: order left components. 2801 - 3400 4 > 3400 5 [26] Striker for anti-pushback function [18] Buffer Nο Striker for anti-pushback function 2000419 15.7 [27] Cover cap for striker for anti-pushback [20] MUL striker function TI Nº 3 793493 Screw-on R01.1 Natural silver Can be routed in 798223 R05.3 Medium bronze R06.2 Jet black R07 2 Traffic white ≤ 2400 6 [31] End stop, profile-related 2401 - 3400 8 Alternatively: > 3400 10 Rubber buffer → from page 87 [21] Cover cap for MUL striker, only in combination 30 with MUL striker, screw-on. **RAL 7004** End stop Signal grey 9 Nο **RAL 9005** Jet black R01.1 Natural silver 819632 R05.3 Medium bronze 819631 [32] End stop packer, profile-related R06.2 Jet black 798979 R07.2 Traffic white 808054 **RAL 7004** Signal grey **RAL 9005** Jet black Ī Ë ≤ 2400 6 [33] Stopper, cannot be used in conjunction 2401 - 3400 8 with a control unit with SoftOpen / SoftClose > 3400 10 SoftStop on the espagnolette side. [24] Pin, adjustable, for anti-pushback ₩1 Alternatively: function [37] Rubber buffer → from page 87 Nο \*Gasket compression adjustable 25 mm 895977 Stopper 26 mm 895984 27 mm 895989 [34] Packer; profile-related quantity [3] 32 mm 895994

35.5 mm

39.5 mm

36 mm

42 mm

44 mm

49 mm

53.5 mm

858629

895999

839049

861551

896002

896005

839048

Packer

14


Operating sequence control set, profile-

Only use the number of packers that is specified in the profile assessment.

#### Contents:

[*]	•	#
[49]	Bolt	1
[50]	Stop, routed	1
[51]	Countersunk screw, M5 x 20	1
[52]	Anti-lifting device	1

## Optional



[4] Only use the number of packers that is specified in the profile assessment.




## Hardware overviews

**Timber** Diagram C



## 4.1.4 Diagram C'





**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a]	Corner drive	With E cam	7 6
[1b]		With V cam	`₩ 2
<b>8</b> <sup>#</sup>		8	Nº
1		Е	260275
1		V	260272





[4]	Espagnolette	extension	, SRH > 2000	J mm
		<b>8</b> *	0	Nº
200	Υ	-	-	308267
400	Υ	_	_	297858
600	Υ	1	V	337711

Size-specific combinations:

#### First or second opening sash

<b>‡</b>	-	8	0	Nο
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	-	-	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	-	-	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	_	-	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	_	-	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

## Centre lock (CL)

[5]	CL componer	<b>ıt</b> , horizonta	al	
-		<b>8</b> *	0	Nº
200	Υ	-	_	308267
400	Υ	_	_	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

Size-specific combinations:

#### First or second opening sash

←→		1+	8	9	Nο
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6]	CL componer	`₩ 13		
		<b>8</b> *	<b>©</b>	Nº
130	Υ	1	K	862364

[7]	CL componen	<b>t</b> , vertical,	on the mullic	n
		<b>9</b> **	<b>©</b>	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	K	862366

Size-specific combinations:

#### First opening sash:

<u> </u>		<b>8</b> *	<u>@</u>	No
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	-	-	297858
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366

IMO\_559\_EN\_v1 · 05 / 2022 · **49** 

₫	-	<b>3</b>	8	Nο
3401 – 3600	600 KU	1	K	862366
	400 KU	_	_	297858
	600 KU	1	K	862366
	600 KU	1	K	862366

#### Second opening sash:

Second opening sasii.				
<u>‡</u>		8	8	Nº
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	_	-	297858
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366
3401 – 3600	600 KU	1	K	862366
	400 KU	_	-	297858
	600 KU	1	K	862366
	600 KU	1	K	862366

[8]	Roller track	₩ 1-2
-		Nº
3200		807733
6400		807734

[9]	Roller unit	₩ 4
		Nº
41	Left	862367
	Right	862368



## **INFO**

DIN L: order right components.

DIN R: order left components.

[90]	Stabilisation unit	
		Nº
41	Left	891368






#### **INFO**

DIN L: order right components.

DIN R: order left components.





#### INFO

DIN L: order right components.

DIN R: order left components.





[30]

#### **INFO**

DIN L: order right components.

DIN R: order left components.

Control unit with Soft function

[11] Centre	closer, adjustable	
		Nº
41	Left	862395
	Right	862396
<u>₹</u>		
≤ 2400		6
2401 – 3400		8
> 3400		10




#### INFO

DIN L: order right components.

DIN R: order left components.



[12] MUL locking cam, adjustable		
*	-	Nº
Gasket compression adjustable	25	895955
	26	895966
	27	895970
	32	786728
	35.5	858628
	36	895972
	39.5	839047
	42	861550
	44	895973
	45.8	791838
	47.8	788696
	49	895974
	53.5	839045
<u>*</u>		••
≤ 2400		6
2401 – 3400		8
> 3400		10



CIL_1	
[17] Striker, diagram C	
T T	Nº
Screw-on	806824
<u> </u>	
≤ 2800	3
2801 – 3400	4
> 3400	5
[18] Buffer, diagram C	
	Nº
15.7	2000419
[20] MUL striker	
1	Nº
Screw-on	793493

a a a a a a a a a a a a a a a a a a a	Nº
Can be routed in	798223
₫	
≤ 2400	6
2401 – 3400	8
> 3400	10

[21] Cover cap for MUL striker, only in combination

with	MUL striker, screw-on.	<i>'</i>
Roto	6	Nº
R01.1	Natural silver	819632
R05.3	Medium bronze	819631
R06.2	Jet black	798979
R07.2	Traffic white	808054
<b>Ţ</b>		••
≤ 2400		6
2401 – 3400		8
> 3400		10

[24] Pin, adjustable, for anti-pushback			
*		Nο	
Gasket compression adjustable	25 mm	895977	
	26 mm	895984	
	27 mm	895989	
	32 mm	895994	
	35.5 mm	858629	
	36 mm	895999	
	39.5 mm	839049	
	42 mm	861551	
	44 mm	896002	
	49 mm	896005	
	53.5 mm	839048	


[25]	Centre closer, adjustable, for antipushback function	` <b>₩</b> 1
	00	No
41	Left	862395
	Right	862396
[26]	Striker for anti-pushback function	`₩ 1
		Nō
Striker	for anti-pushback function	810279

	ver cap for striker for ar ction	nti-pushback 📜 1
Roto	6	Nº
R01.1	Natural silver	828482
R05.3	Medium bronze	828483
R06.2	Jet black	809717
R07.2	Traffic white	819351
[04] E	I ata a sus Classical	~ ~


[31] End stop, profile-related

Alternatively:





#### Optional



<sup>[6]</sup> Only use the number of packers that is specified in the profile assessment.



<sup>[5]</sup> Only use the number of packers that is specified in the profile assessment.


#### Hardware overviews

**Timber** Diagram C'



# 4.2 PVC

## 4.2.1 Diagram A, K





**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a]	Corner drive	With E cam	` <b>₩</b> 2
[1b]		With V cam	`₩ 2
<b>8</b> *		<b>©</b>	Nº
1	E		260275
1	\	/	260272



[4]	Espagnolette	extension	, SRH > 2000	) mm
-		<b>8</b> *	0	No
200	Υ	-	-	308267
400	Υ	_	_	297858
600	Υ	1	V	337711

#### Size-specific combinations:

<u>‡</u>		<b>9</b> **	9	Nº
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	_	_	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	_	_	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	_	_	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	_	_	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

## Centre lock (CL)

[5]	CL component	, horizont	al	
		<b>8</b> <sup>#</sup>	0	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

#### Size-specific combinations:

l≪⇒i	-	4	8	8	Nō
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362

←→	-	1-	8	8	Nº
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6]	CL compone	<b>ent 130</b> , hori	zontal and v	ertical 📜 6
		<b>8</b> *	0	Nº
130	Υ	1	K	862364

[7]	CL component,	vertica	l, on the mullion	
	-	<b>9</b> **	8	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	K	862366

#### Size-specific combinations:

<u>‡</u>		<b>8</b> *	9	No
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	-	-	297858
	600 KU	1	K	862366
	200 KU	-	_	308267
	600 KU	1	Κ	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366
3401 – 3600	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366
	600 KU	1	K	862366

[9]	Roller unit		₩ 2
			No
41		Left	862367
		Right	862368



Contents:

Activator

Control unit with Soft function

[\*]

[29]

[30]


> 3400

	Stabilisation		Nº	*
41		Left Right	891368 891369	
l <b>←→</b> I			-	≤ 2400 2401 – 3400
≤ 211	0		1	> 3400
> 211	0		2	[15] Strik
[10]	0 . 1			
נוטן	the centre 🗲 i		nd in 📜 1-3	Striker to prev
[10]	the centre $\rightarrow$ n	from page 85 on the mullion side): t with Soft function (i		[16] Hand
[10]	the centre $\rightarrow r$ Alternatively (control unit se	from page 85 on the mullion side): t with Soft function (i		Striker to prevo
41	the centre $\rightarrow r$ Alternatively (control unit se	from page 85 on the mullion side): t with Soft function (i from page 85	incl. 📜 1	[16] Hand Rece
	the centre $\rightarrow r$ Alternatively (control unit se	from page 85 on the mullion side): t with Soft function (if the page 85	incl. ≒ 1	[16] Hand
41	the centre → find the centre	from page 85 on the mullion side): t with Soft function (if the page 85 Left Right	incl.	[16] Hand Rece CTL_
	the centre → f Alternatively (c Control unit se activator) → f  Control unit se	from page 85 on the mullion side): t with Soft function (if the page 85 Left	incl.	[16] Hand Rece CTL_  [17] Strike  Screw-on
41	the centre → f Alternatively (c Control unit se activator) → f  Control unit se	from page 85 on the mullion side): t with Soft function (if the page 85 Left Right set with Soft function	incl.	[16] Hand Rece CTL_ [17] Strik

#

[11] Centre of	loser, adjustable	
		Nº
41	Left	862395
	Right	862396
₫		00
≤ 2400		3
2401 - 3400		4

[12] MUL locking cam, adjustable		
*		No
Gasket compression adjustable	25	895955
	26	895966
	27	895970
	32	786728
	35.5	858628
	36	895972
	39.5	839047
	42	861550
	44	895973
	45.8	791838
	47.8	788696
	49	895974



≤ 2400

> 3400

2401 - 3400

[31] End stop, profile-related


3

5

4

Diagram A, K






#### **Optional**



[7] Only use the number of packers that is specified in the profile assessment.



# 4.2.2 Diagram A', K'





**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a] [1b]	Corner drive With E can With V can	
8	<b>©</b>	Nº
1	E	260275
1	V	260272



[4]	Espagnolette	extension	, SRH > 2000	) mm
		<b>8</b> *	9	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	V	337711

#### Size-specific combinations:

<b>‡</b>	-	8	<u>@</u>	Nº
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	-	-	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	_	-	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	_	-	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	_	-	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

## Centre lock (CL)

[5]	CL component,	horizon	tal	
		<b>8</b> *	8	Nº
200	Υ	-	-	308267
400	Υ		_	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

#### Size-specific combinations:

l≪⇒i	-	4	8	8	Nō
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362

←→	-	1-	<b>8</b> *	8	Nο
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6]	CL compone	<b>ent 130</b> , hori	zontal and v	ertical 📜 6
		<b>8</b> *	0	Nº
130	Υ	1	K	862364

[7]	CL component,	vertica	l, on the mullion	
-		<b>9</b> **	<u>©</u>	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	K	862366

#### Size-specific combinations:

<u>‡</u>		<b>8</b> *	9	No
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	-	-	297858
	600 KU	1	K	862366
	200 KU	-	_	308267
	600 KU	1	Κ	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366
3401 – 3600	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366
	600 KU	1	K	862366

[9]	Roller unit	₩ 2
	0.0	Nº
41	Left	862367
	Right	862368



#### **INFO**

DIN L: order right components.

DIN R: order left components.


[90] Stabilisat	ion unit	
	8:8	Nº
41	Left	891368
	Right	891369
←→		-
≤ 2110		1
> 2110		2



#### **INFO**

DIN L: order right components.

DIN R: order left components.





#### **INFO**

DIN L: order right components.

DIN R: order left components.



[*]	•	#
[29]	Activator	1
[30]	Control unit with Soft function	1



#### **INFO**

DIN L: order right components.

DIN R: order left components.

[11]	Centre closer, adjustable	
		Nº
41	Left	862395





#### **INFO**

DIN L: order right components.

DIN R: order left components.

<u> </u>		
[12] MUL locking cam, adjustat	ole	
*		Nº
Gasket compression adjustable	25	895955
	26	895966
	27	895970
	32	786728
	35.5	858628
	36	895972
	39.5	839047
	42	861550
	44	895973
	45.8	791838
	47.8	788696
	49	895974
	53.5	839045
<u></u>		-
≤ 2400		3
2401 – 3400		4
> 3400		5
[15] Striker to prevent incorrect	t operation	Ä
•		Nº
Striker to prevent incorrect operation		822789

•	Nº
Striker to prevent incorrect operation	822789
[16] Handle (200 mm handle length) -> CTL_	1 7 1
<b>Recessed grip</b> (43 mm distance), not sh. CTL_1	. → `\ 1


[17] Striker	
T	Nº
Screw-on	744579
<u>₹</u>	#
≤ 2800	3
2801 – 3400	4
> 3400	5
[40] D ((	\

[18] Buffer	₹2
	Nº
14	635307



[20] N	IUL striker		
THE STATE OF THE S			No
Screw-or	1		793493
<b></b>			-
≤ 2400			3
2401 – 34	100		4
> 3400			5
	<b>over cap for Ml</b> vith MUL striker, s	<b>JL striker</b> , only in co screw-on.	mbination
<b>PROTECTION</b>			No
R01.1	Natural silver		819632
R05.3	Medium bro	nze	819631
R06.2	Jet black		798979
R07.2	Traffic white		808054
<u>‡</u>			***
≤ 2400			3
2401 – 3	100		4
> 3400			5
А	<b>nd stop</b> , profile-r Iternatively: ubber buffer → <i>f</i>		` <b></b> 1
	<b>3</b>		No
End stop	RAL 7004	Signal grey	2006569
	RAL 9005	Jet black	349600
[32] E	nd stop packer,	profile-related	
	<b>3</b>		No
	RAL 7004	Signal grey	2007421
	RAL 9005	Jet black	477263
S A			n े <b>ॹ</b> 1
			No
Stopper			800196
[24] .		[8]	
[34] P	acker; profile-rela	ated quantity (°)	NIO
-			No
Packer			800197


## **Optional**



[8] Only use the number of packers that is specified in the profile assessment.



# 4.2.3 Diagram A, K | RC 2 / RC 2 N





**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a] Corner	<b>drive</b> With E cam	` <b>₩</b> 2
[1b]	With V cam	`₩ 2
<b>8</b> *	<b>©</b>	Nº
1	Е	260275
1	V	260272

[4]	Espagnolette	extensior	n, SRH > 2000	) mm
		<b>8</b> *	8	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	V	337711

[2a] VT espagnolette → from page 77

#### Size-specific combinations:

<u>₹</u>	-	<b>9</b> *	8	Nº
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	-	-	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	-	-	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	-	-	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	-	-	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

#### Centre lock (CL)

[5]	CL componer	<b>nt</b> , horizonta	al	
		<b>8</b> *	0	No
200	Υ	-	-	308267
400	Υ	_	_	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

#### Size-specific combinations:

l <b>←→</b> l		1.	<b>8</b> **	9	Nο
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267

←→		14	8	9	Nο
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6]	CL componen	<b>it 130</b> , hor	izontal and ve	ertical 📜 6
		<b>8</b> *	0	No
130	Υ	1	K	862364

[7]	CL component	t, vertical,	on the mullion	
		<b>8</b> *	0	Nο
400	Υ	1	K	862365
600	Υ	1	K	862366

Nο

#### Size-specific combinations:

		_	_	
2000 – 2200	400 KU	1	K	862365
	600 KU	1	K	862366
2201 – 2300	400 KU	1	K	862365
	400 KU	1	K	862365
	400 KU	1		862365
2301 – 2500	400 KU	1	K	862365
	400 KU	1	K	862365
	600 KU	1	K	862366
2501 – 2700	400 KU	1	K	862365
	600 KU	1	K	862366
	600 KU	1	K	862366
2701 – 2900	400 KU	1	K	862365
	600 KU	1	K	862366
	400 KU	1	K	862365
	400 KU	1	K	862365
2901 – 3100	400 KU	1	K	862365
	600 KU	1	K	862366
	600 KU	1	K	862366
	400 KU	1	K	862365
3101 – 3300	400 KU	1	K	862365
	600 KU	1	K	862366
	600 KU	1	K	862366
	600 KU	1	K	862366
3301 – 3500	400 KU	1	K	862365
	600 KU	1	K	862366
	600 KU	1	K	862366
	400 KU	1	K	862365
	400 KU	1	K	862365
3501 – 3600	400 KU	1	K	862365
	600 KU	1	K	862366
	600 KU	1	K	862366
	600 KU	1	K	862366
	400 KU	1	K	862365

Roto

[9] Roller ι	unit	₹ 2	*	-	Nο
	0.0	Nº		42	86155
1	Left	862367		44	89597
	Right	862368		45.8	79183
				47.8	78869
90] Stabilis	sation unit			49 53.5	89597 83904
•		No		55.5	03904
<b>!</b> 1	Left	891368			
	Right	891369	± ≤ 2100		4
		-	2101 – 2700		5
<b>→</b> I		0.0	2701 – 3300		6
2110		1	> 3300		7
2110		2	[15] SEC striker to prevent incorre	oot.	`
10] Contro	I unit, on the mullion side ar	nd in 📜 1-3	operation	ect	ļ
	tre → <i>from page 85</i>	, 0			NIO
Alternat	tively (on the mullion side):				No
	unit set with Soft function (i	ncl. 📜 1	SEC striker to prevent incorrect operation		82279
	or) → from page 85		[16] Handle, lockable (200 mm hand	lle lenath	) <del>&gt;</del>
-	0.0	Nº	CTL_1		
<b>l</b> 1	Left	862371	Recessed grip (43 mm distance	e), not sh	. → `\
	Right	862372	CTL_1		
Alternat		on, on	Screw-on		_
Alternat 10] Control	tively:		Screw-on		79822
Alternat 10] Control ontents:	tively:		Screw-on		79822
Alternat 10] Control ontents:	ively: unit	9 85	Screw-on		79822
Alternat  10] Control ontents:  [*]   Activate	ively: unit	#	Screw-on		79822 3 4 5
Alternation 10] Control ontents:  [*] Q  29] Activation Control	ively: unit	# 1	Screw-on		79822 3 4 5
Alternation   Alternation   10] Control   contents: [*]	unit  or unit with Soft function	# 1	Screw-on		79822 3 4 5
Alternation Alternation Alternation Alternation Control Contro	or unit with Soft function  closer, adjustable	# 1 1	Screw-on		79822
Alternation Alternation Alternation Alternation Control Contro	or unit with Soft function  closer, adjustable	# 1 1 1 Nº	Screw-on		79822 3 4 5 Nº2 63530
Alternation   Al	or unit with Soft function  closer, adjustable  Left	# 1 1 1 Nº 862395 862396	Screw-on		79822 3 4 5 Nº 63530
Alternation Alternation Alternation Alternation Control Contro	or unit with Soft function  closer, adjustable  Left	# 1 1 1 Nº 862395 862396	Screw-on  \$\frac{1}{2}\$ \$\leq 2800\$  \$\leq 2801 - 3400\$  \$\leq 3400\$  [18] Buffer  14  [20] SEC MUL striker  SEC MUL striker		79822 3 4 5 Nº2 63530 N°2 83368
Alternation Alternation Alternation Alternation Control Contro	or unit with Soft function  closer, adjustable  Left	# 1 1 1 Nº 862395 862396	Screw-on		79822 3 4 5 Nº 63530 Nº
Alternation Altern	or unit with Soft function  closer, adjustable  Left	# 1 1 1 Nº 862395 862396	Screw-on  \$\frac{1}{2}\$ \$\leq 2800\$  \$\leq 2801 - 3400\$  \$\leq 3400\$  [18] Buffer  14  [20] SEC MUL striker  SEC MUL striker		79822 3 4 5 Nº 63530 Nº 83368
Alternat  10] Control  ontents:  [*]	or unit with Soft function  closer, adjustable  Left	# 1 1 1 Nº 862395 862396 4 5	Screw-on		79822 3 4 5 Nº 63530 N° 83368 4 5
Alternat  10] Control  ontents:  [*]	or unit with Soft function  closer, adjustable  Left	# 1 1 1 1 Nº 862395 862396 4 5 6	Screw-on		79822 3 4 5 Nº2 63536 N°2 83368 4 5 6
Alternation   Al	or unit with Soft function  closer, adjustable  Left Right	# 1 1 1 1 Nº 862395 862396 4 5 6	Screw-on		79822 3 4 5 Nº 63530 N° 83368 4 5
Alternation   Al	or unit with Soft function  closer, adjustable  Left Right  cking cam, adjustable	# 1 1 1 No 862395 862396 4 5 6 7	Screw-on		79822 3 4 5 Nº2 63536 N°2 83368 4 5 6 7
Alternation   Alternation   Alternation   Control   Control     Activate   30   Control     Control     Control	closer, adjustable Left Right  ccking cam, adjustable	# 1 1 1 Nº 862395 862396 4 5 6 7	Screw-on		79822 3 4 5 Nº2 63530 N°2 83368 4 5 6 7
Alternat  10] Control ontents:  [*]	closer, adjustable  Left Right  closer, adjustable	# 1 1 1 1 Nº 862395 862396 4 5 6 7	Screw-on		79822 3 4 5 Nº2 63536 N°2 83368 4 5 6 7
Alternat  10] Control  contents:  [*]	closer, adjustable  Left Right  closer, adjustable	# 1 1 1 Nº 862395 862396 4 5 6 7	Screw-on		79822 3 4 5 Nº2 63530 N°2 83368 4 5 6 7
Alternat [10] Control Contents:  [*]	or unit with Soft function  closer, adjustable  Left Right  cking cam, adjustable	# 1 1 1 1 Nº 862395 862396 4 5 6 7  Nº 225 895955 26 895966	Screw-on		79822 3 4 5 Nº2 63536 N°2 83368 4 5 6 7

36

895972 39.5 839047



*	-	Nº
Gasket compression adjustable	25 mm	895977
	26 mm	895984
	27 mm	895989
	32 mm	895994
	35.5 mm	858629
	36 mm	895999
	39.5 mm	839049
	42 mm	861551
	44 mm	896002
	49 mm	896005
	53.5 mm	839048
[25] Centre closer, adjustab pushback function	le, for anti-	`₩:
		No
41 Left		862395
Right		862396
INFO DIN L: order right con	anononte	


[26] Striker for anti-pushback function	7 2
•	No
Striker for anti-pushback function	810279
[27] Cover cap for SEC MUL striker / stri	ker for

anti	anti-pushback function				
Roto	8	Nº			
R01.1	Natural silver	828482			
R05.3	Medium bronze	828483			
R06.2	Jet black	809717			
R07.2	Traffic white	819351			
T		2			
<u>‡</u>		• •			
≤ 2100		6			
2101 – 2700		7			
2701 – 3300		8			
> 3300		9			

	[31] End stop, profile-related  Alternatively:			
	ber buffer → fro	m page 87		
	<b>3</b>	1	Nο	
End stop	RAL 7004	Signal grey	2006569	
	RAL 9005	Jet black	349600	

[32] End stop packer, profile-related					
	<b>3</b>	1	Nº		
	RAL 7004	Signal grey	2007421		

[9] Only use the number of packers that is specified in the profile assessment.




#### **Optional**





## 4.2.4 Diagram C





**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a] [1b]	Corner drive	With E cam With V cam	<b>≒</b> 6 <b>≒</b> 2
<b>8</b> *		8	Nº
1		Е	260275
1		V	260272





[4]	Espagnolette extension, Shr > 2000 IIIII					
		<b>8</b> *	9	Nº		
200	Υ	-	-	308267		
400	Υ	_	_	297858		
600	Υ	1	V	337711		

Size-specific combinations:

#### First or second opening sash

<u>‡</u>		<b>8</b> **	9	Nº
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	-	-	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	-	-	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	_	-	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	_	-	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

## Centre lock (CL)

[5]	CL component, horizontal						
-	*****	<b>9</b> *	9	Nº			
200	Υ	-	-	308267			
400	Υ	_	-	297858			
1190	Υ	1	K	862360			
1440	Υ	1	K	862361			
1790	Υ	2	K	862362			
2190	Υ	2	K	862363			

Size-specific combinations:

#### First or second opening sash

l <del>≪∍</del> l	-	4	8	9	No
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6]	CL component 130, horizontal					
-		8	<u>@</u>	No		
130	Υ	1	K	862364		

[7]	CL component	<b>t</b> , vertical,	on the mullior	1
-		<b>9</b> *	8	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	K	862366

Size-specific combinations:

#### First opening sash:

•	•				
<u>‡</u>			<b>8</b> **	9	No
2000 – 2200		200 KU	-	-	308267
		600 KU	1	K	862366
2201 – 2400		400 KU	-	-	297858
		600 KU	1	K	862366
2401 – 2600		600 KU	1	K	862366
		600 KU	1	K	862366
2601 – 2800		600 KU	1	K	862366
		200 KU	-	-	308267
		600 KU	1	K	862366
2801 – 3000		200 KU	-	-	308267
		600 KU	1	K	862366
		200 KU	-	-	308267
		600 KU	1	K	862366
3001 – 3200		400 KU	-	-	297858
		600 KU	1	K	862366
		200 KU	-	-	308267
		600 KU	1	K	862366
3201 – 3400		400 KU	-	-	297858
		600 KU	1	K	862366
		400 KU	-	-	297858
		600 KU	1	K	862366



₫		8	8	Nο	Control unit set with Soft function (incl. activator) → from page 85	₩ 1-2
3401 – 3600	600 KU	1	K	862366		Nº
	400 KU	-	-	297858		
	600 KU	1	K	862366	41 Left Right	862371 862372
	600 KU	1	K	862366	Tilgitt	002372
Second openi	ng sash:				[*] Control unit set with Soft function, of	on 📜 2
₫		<b>8</b> *	9	No	the espagnolette side → from page 85	/II <del>VI</del> Z
2000 – 2200	200 KU	-	-	308267	Alternatively:	
	600 KU	1	K	862366	[10] Control unit	
2201 – 2400	400 KU	_	-	297858	Contents:	
	600 KU	1	K	862366	[*]	#
2401 – 2600	600 KU	1	K	862366	[29] Activator	1
	600 KU	1	K	862366	[30] Control unit with Soft function	1
2601 – 2800	600 KU	1	K	862366		
	200 KU	_	-	308267	[11] Centre closer, adjustable	
	600 KU	1	K	862366		Nº
2801 – 3000	200 KU	-	-	308267		
	600 KU	1	K	862366	41 Left	862395
	200 KU	-	-	308267	Right	862396
	600 KU	1	K	862366	₹	
3001 – 3200	400 KU	-	-	297858	¥ ≤ 2400	6
	600 KU	1	K	862366	2401 – 3400	8
	200 KU	-	-	308267	> 3400	10
	600 KU	1	K	862366		
3201 – 3400	400 KU	-	-	297858	[12] MUL locking cam, adjustable	
	600 KU	1	K	862366		NIO
	400 KU	-	-	297858	*	No
	600 KU	1	K	862366	Gasket compression adjustable 25	895955
3401 – 3600	600 KU	1	K	862366	26 27	895966 895970
	400 KU	-	-	297858	32	786728
	600 KU	1	K	862366	35.5	858628
	600 KU	1	K	862366	36	895972
[9] Roller ui	nit			7 1	39.5	839047
[9] Roller u				₩ 4	42 44	861550 895973
				No	45.8	791838
41	Left			862367	47.8	788696
	Right			862368	49	895974
[90] Stabilisa	ation unit				53.5	839045
	0:0			Nº	<b>†</b>	
41	Left			891368	± ≤ 2400	6
	Right			891369	2401 – 3400	8
				_	> 3400	10
←→					[15] Christon to manage in comment and and	<b>—</b> 1
≤ 2110				2	[15] Striker to prevent incorrect operation	
> 2110				4		Nō
	unit, on the m		le and in	`₩ 2-6	Striker to prevent incorrect operation	822789
	re → from pag vely (on the mu		e):		[16] Handle (200 mm handle length) → CTL_	_1 📜 2



#### **Recessed grip** (43 mm distance), not sh. → [25] Centre closer, adjustable, for antipushback function Nο $\Pi:\Pi$ [17] Striker 41 Left 862395 Nο TI Right 862396 Screw-on 744579 INFO 1 Ä DIN L: order right components. ≤ 2800 3 DIN R: order left components. 2801 - 3400 4 > 3400 5 [26] Striker for anti-pushback function ₩1 [18] Buffer Nο Nο Ħ Striker for anti-pushback function 810279 635307 14 [27] Cover cap for striker for anti-pushback [20] MUL striker function TI Nº Nο 3 793493 Screw-on R01.1 Natural silver 828482 R05.3 Medium bronze 828483 Ä R06.2 Jet black 809717 R07.2 Traffic white 819351 ≤ 2400 6 2401 - 3400 8 [31] End stop, profile-related **2** > 3400 10 Alternatively: [21] Cover cap for MUL striker, only in combination Rubber buffer → from page 87 with MUL striker, screw-on. 30 Nο 9 Nο 2006569 **RAL 7004** End stop Signal grey R01.1 Natural silver 819632 **RAL 9005** 349600 Jet black R05.3 Medium bronze 819631 R06.2 Jet black 798979 [32] End stop packer, profile-related R07.2 Traffic white 808054 Nο **RAL 7004** Signal grey 2007421 Ä **RAL 9005** Jet black 477263 ≤ 2400 6 2401 - 3400 8 [33] Stopper, cannot be used in conjunction **...** 2 10 > 3400 with a control unit with SoftOpen / SoftClose [24] Pin, adjustable, for anti-pushback ₩ 1 SoftStop on the espagnolette side. function Alternatively: Nο \*[37] Rubber buffer → from page 87 Gasket compression adjustable 25 mm 895977 Nο 26 mm 895984 Stopper 800196 27 mm 895989 32 mm 895994 [34] Packer; profile-related quantity [10] 35.5 mm 858629 36 mm 895999 Nο 39.5 mm 839049 800197 Packer 42 mm 861551 44 mm 896002 Operating sequence control set, profile-49 mm 896005 53.5 mm 839048 Nο

[10] Only use the number of packers that is specified in the profile assessment.




861110


833201

14

31.3



#### Optional



[11] Only use the number of packers that is specified in the profile assessment.




# Hardware overviews PVC

Diagram C



## 4.2.5 Diagram C'





# **Application range**

**SRW**: 1500 - 3000 mm **SRH**: 2000 - 3600 mm **S.kg**: max. 400 kg

[1a] (	Corner drive	With E cam	₩6
[1b]		With V cam	₩2
8		<u></u>	Nº
1	Е		260275
1	V		260272





[4]	Espagnoiette	extension	, SKH > 2001	) mm
		<b>8</b> *	8	Nº
200	Υ	-	-	308267
400	Υ	-	_	297858
600	Υ	1	V	337711

Size-specific combinations:

# First or second opening sash

<u>‡</u>		<b>8</b> **	9	Nº
2000 – 2200	200 KU	-	-	308267
2201 – 2400	400 KU	-	-	297858
2401 – 2600	200 KU	-	-	308267
2601 – 2800	400 KU	-	-	297858
2801 – 3000	600 KU	1	V	337711
3001 – 3200	200 KU	_	-	308267
	600 KU	1	V	337711
3201 – 3400	400 KU	_	-	297858
	600 KU	1	V	337711
3401 – 3600	600 KU	1	V	337711
	600 KU	1	V	337711

# Centre lock (CL)

[5]	CL componer	<b>ıt</b> , horizonta	al	
-	*****	<b>9</b> *	9	Nº
200	Υ	-	-	308267
400	Υ	_	_	297858
1190	Υ	1	K	862360
1440	Υ	1	K	862361
1790	Υ	2	K	862362
2190	Υ	2	K	862363

Size-specific combinations:

# First or second opening sash

←→		1+	8	8	Nο
1500 – 1660	1190	1180	1	K	862360
1661 – 1910	1440	1430	1	K	862361
1911 – 2110	1440	1430	1	K	862361
	200	200	-	-	308267
2111 – 2260	1790	1780	2	K	862362
2261 – 2460	1790	1780	2	K	862362
	200	200	-	-	308267
2461 – 2660	2190	2180	2	K	862363
2661 – 2860	200	200	-	-	308267
	2190	2180	2	K	862363
2861 – 3000	400	400	-	-	297858
	2190	2180	2	K	862363

[6]	CL componer	<b>nt 130</b> , hori	zontal	₩ 13
-	<u>-</u>	<b>8</b> *	9	No
130	Υ	1	K	862364

[7]	CL componen	<b>t</b> , vertical,	on the mullio	า
-	*****	<b>9</b> *	<u>©</u>	Nº
200	Υ	-	-	308267
400	Υ	-	-	297858
600	Υ	1	K	862366

Size-specific combinations:

# First opening sash:

<u>‡</u>		8	<u>@</u>	Nº
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3001 – 3200	400 KU	-	-	297858
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
3201 – 3400	400 KU	-	-	297858
	600 KU	1	K	862366
	400 KU	-	-	297858
	600 KU	1	K	862366

<u>‡</u>		<b>8</b> *	<u>@</u>	Nº
3401 – 3600	600 KU	1	Κ	862366
	400 KU	_	_	297858
	600 KU	1	K	862366
	600 KU	1	K	862366
Second openin	u sash.			
<u>‡</u>	g 5d511.	<b>8</b> *	<u>©</u>	Nº
2000 – 2200	200 KU	-	-	308267
	600 KU	1	K	862366
2201 – 2400	400 KU	-	-	297858
	600 KU	1	K	862366
2401 – 2600	600 KU	1	K	862366
	600 KU	1	K	862366
2601 – 2800	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366
2801 – 3000	200 KU	-	-	308267
	600 KU	1	K	862366
	200 KU	-	-	308267
	600 KU	1	K	862366

400 KU

600 KU

200 KU

600 KU

400 KU

600 KU

400 KU

600 KU

600 KU

400 KU

600 KU

1

Κ

Κ

Κ

Κ

Κ

		600 KU	1	K	862366
[9]	Roller unit				₩ 4
					Nº
41		Left			862367
		Right			862368



3001 - 3200

3201 - 3400

3401 - 3600

#### **INFO**

DIN L: order right components.

DIN R: order left components.


[90] Stabilisa	ation unit	
		Nº
41	Left	891368
	Right	891369
←→		
≤ 2110		2
> 2110		4



#### INFO

DIN L: order right components.

DIN R: order left components.





#### **INFO**

DIN L: order right components.

DIN R: order left components.





297858

862366

308267

862366

297858

862366

297858

862366

862366

297858

862366

[*]		#
[29]	Activator	1
[30]	Control unit with Soft function	1



#### **INFO**

DIN L: order right components.

DIN R: order left components.

[11] Centre of	closer, adjustable	
		Nº
41	Left	862395
	Right	862396
<u>₹</u>		**
≤ 2400		6
2401 – 3400		8
> 3400		10



#### **INFO**


DIN L: order right components.

DIN R: order left components.


[12] MUL locking cam, adjustable				
*	-	No		
Gasket compression adjustable	25	895955		
	26	895966		
	27	895970		



*		-	Nº	Roto	1		Nο
		32	786728	R07.2	Traffic white		808054
		35.5	858628				
		36	895972	₹			
		39.5	839047	≤ 2400			6
		42	861550	2401 – 3400	)		8
		44 45.8	895973 791838	> 3400			10
		45.8	788696				~ .
		49	895974			or anti-pushback	7 1
		53.5	839045		ction		NIO
Ā			_	*			No
<u>‡</u>			••	Gasket com	pression adjustable	25 mm	895977
≤ 2400			6			26 mm 27 mm	895984 895989
2401 – 3400			8			32 mm	895994
> 3400			10			35.5 mm	858629
[15] Caril			~ 1			36 mm	895999
[15] Stril	ker to prevent incorrect	operation				39.5 mm	839049
			No			42 mm	861551
Striker to pre	event incorrect operation		822789			44 mm	896002
	·					49 mm	896005
[16] Han	dle (200 mm handle leng	th) <del>&gt;</del> CTL_	1 7 2			53.5 mm	839048
Rec CTL	<b>essed grip</b> (43 mm distar _1	nce), not sh	. → 📜 2		ntre closer, adj shback functio	ustable, for anti- n	`₩ 1
[17] Stril	ker						No
T			No	41	Let	ft	862395
Screw-on			744579		Rig	ght	862396
<b>T</b>			~	[26] Stri	iker for anti-pu	shback function	`₩ 1
<u>‡</u>							Nº
≤ 2800			3				
2801 – 3400			4	Striker for a	nti-pushback functio	n	810279
> 3400	fer, diagram C	_	5		er cap for stri	ker for anti-pushba	ack 📜 1
	ier, diagram C		Nº	<b>3</b> 9			Nº
				Roto	P Natural silver		
14			635307	R01.1 R05.3	Natural silver Medium bron	70	828482 828483
[20] MUI	l striker			R06.2	Jet black	ze	809717
	L Striker		NIO	R07.2	Traffic white		819351
Ad			Nō	1107.12	Traine Trinte		0.0001
Screw-on			793493	[31] End	<b>l stop</b> , profile-re	elated	`₩ 2
<u> </u>					ernatively:		
				[37] Rub	ber buffer → fr	om page 87	
≤ 2400			6		<b>3</b>		Nº
2401 – 3400			8	End stop	RAL 7004	Signal grey	2006569
> 3400			10	End Stop	RAL 7004 RAL 9005	Jet black	349600
	<b>er cap for MUL striker</b> , MUL striker, screw-on.	only in con	nbination	[32] End	l stop packer,		343000
Roto	1		Nº		<b>3</b>	1	Nº
R01.1	Natural silver		819632		RAL 7004	Signal grey	2007421
R05.3	Medium bronze		819631		RAL 9005	Jet black	477263
R06.2	Jet black		798979				



# **Optional**



<sup>[13]</sup> Only use the number of packers that is specified in the profile assessment.



<sup>[12]</sup> Only use the number of packers that is specified in the profile assessment.



# 5 Espagnolettes


# 5.1 T&T espagnolettes

# 5.1.1 Backset 25, 30, 35, 40, 50 mm


Size-specific combinations:

<u>‡</u>	
2000 – 2400	1890
2401 – 3600	2290

#### **Basic security**



#### Lockable



 Subject to change.
 Roto Patio Inowa | 400
 IMO\_559\_EN\_v1 · 05 / 2022 · 77



# Second opening sash

4	· • ·			0	No	
1890	25	1000	_	_	809695	
	30	1000			809688	
	35	1000			809669	
	40	1000	_	_	809649	
	50	1000	_	_	809608	
2290	25	1000	_	_	809697	
	30	1000	_	_	809690	
	35	1000	_	_	809653	
	40	1000	_	_	809651	
	50	1000	_	_	809610	



# 6 Jigs / tools


# 6.1 Drilling jigs

# 6.1.1 Roller unit / control unit

<b>O</b> 🕰	0		0	0
		R L		
0	0	894737	0	0

		No
Timber	41	894737
PVC	41	894736

# 6.1.2 Centre closer




		No
Timber	41	897691
PVC	41	897690

Subject to change. Roto Patio Inowa | 400 IMO\_559\_EN\_v1 · 05 / 2022 · **79** 


# 6.1.3 Strikers

# **MUL** striker




	i		No
Aluplast smart-slide	Fixed mullion MUL 140041	_	811973
	Fixed mullion MUL 140045	_	807972
Gealan Smoovio	Fixed mullion MUL 5862	-	809328
Rehau	Synego Slide	-	836201
Viking	Timber	_	797967

# **SEC MUL striker**



	i	No
Aluplast smart-slide	Fixed mullion MUL 140045	834696
Gealan Smoovio	Fixed mullion MUL 5862	834689

# Striker for anti-pushback function




	i	No
Aluplast smart-slide	Fixed mullion MUL 140045	834697
Gealan Smoovio	Fixed mullion MUL 5862	834695
Rehau	Synego Slide	838582
Salamander	evolutionDrive Plus+	897744

Other jigs are available upon request.




# 6.1.4 Marker



			Nο
Marker for striker T / PVC, screw-on	_	_	772626


# 6.1.5 Tilt protection device



) Ž	No
Тор	2000345

# 6.2 Tools

# 6.2.1 Hex key



	No
4 mm hex key	208609

 Subject to change.
 Roto Patio Inowa | 400
 IMO\_559\_EN\_v1 · 05 / 2022 · 81


	NΘ
Hex key: 2.5 / 4.0 mm	230764

For height adjustment on the roller unit on the espagnolette side




	No
315	895796

# 6.2.2 Adjustment tools



	No
Adjustment tool: V locking cam	258191
	381574

# 6.2.3 Extractor handle



	No
Extractor handle for stay-bearing pin	899630
Replacement blade	230765



# 6.2.4 Tensioning tool

For control unit with soft function



	i	No
Tensioning tool	For control unit with soft function	837763

# 6.3 Punches

# 6.3.1 Pneumatic punch - PS 100



	i		No
Pneumatic punch – PS 100	For offset cuts	Left	553992
		Right	553993

# **Accessories**

		No
Foot control for pneumatic punch	_	554096
Hand control for pneumatic punch	_	554097

		No
Ruler	Left	230758
	Right	230759
Calliper with centre fixing	Left	324020
	Right	324021
VT calliper	Left	632972
	Right	632973

Subject to change. Roto Patio Inowa | 400 IMO\_559\_EN\_v1 · 05 / 2022 · **83** 



# 6.3.2 Hydropneumatic punch - DUO



	i		No
Hydropneumatic punch – DUO	For offset cuts	Left	262155
		Right	262156

# **Accessories**

		No
Foot control for hydropneumatic punch	_	230760
Hand control for hydropneumatic punch	_	230761


		No
Ruler	Left	230758
	Right	230759
Calliper with centre fixing	Left	324020
	Right	324021
VT calliper	Left	632972
	Right	632973



# 7 Accessories

# 7.1 Control unit set with Soft function

# Positioning options for the control unit



- [A] On the espagnolette side
- [B] On the mullion side
- [1] Control unit without Soft function
- [2] Activator for control unit with Soft function
- [3] Control unit with SoftClose
- [4] Control unit with SoftOpen
- [5] Control unit with SoftStop on the espagnolette side
- [6] Control unit with SoftStop on the mullion side

Control unit	S.kg	Min. SRW	Alignment	Position	Function
Without Soft function	≤ 400 kg	1500	-	On the espagnolette side, on the mullion side	-
		1500 (1 pc.) / > 2110 (2 pcs)	_	Centred	Supports the sash
With SoftClose	≤ 200 kg	1500	Additional control roller faces towards the centre of the sash	On the espagnolette side	Damps the movement of the sash in the locking direction and draws it slowly closed.
With SoftOpen	≤ 200 kg	1500	Additional control roller faces towards the centre of the sash	On the mullion side	Damps the movement of the sash in the opening direction and draws it slowly into the final position.

Control unit	S.kg	Min. SRW	Alignment	Position	Function
With SoftStop	> 200 kg	1500	Additional control roller faces towards the centre of the sash	On the espagnolette side <sup>[14]</sup>	Damps the movement of the sash in the locking direction.
			Additional control roller faces towards the centre of the sash	On the mullion side	Damps the movement of the sash in the opening direction.

#### Control unit set with SoftClose (incl. activator)

Installation position: at the top of the espagnolette side

 $S.kg \le 200 kg$ 

) <u> </u>		3		No
Espagnolette side	41	200 kg	Left	895788
			Right	895789

# Control unit set with SoftOpen (incl. activator)

Installation: at the top of the mullion side

 $S.kg \le 200 kg$ 

) <u> </u>				No
Mullion side	41	200 kg	Left	895792
			Right	895793

# Control unit set with SoftStop (incl. activator)



# **INFO**

The use of control units with SoftStop is only possible up to 300 kg for diagram C.

Control units with SoftStop are only possible in conjunction with an end stop.


Installation: at the top of the mullion side / at the top of the espagnolette side

S.kg > 200 kg

<b>)</b>		3		No
Espagnolette side	41	400 kg	Left	894398
	41	400 kg	Right	894399
Mullion side	41	400 kg	Left	894402
	41	400 kg	Right	894403

# 7.2 Activator spare part for control unit with soft function

The activator is included in the control unit set.





[14] With diagram C only up to 300 kg.






# 7.3 Rubber buffer

Diagram C: cannot be used in conjunction with SoftOpen or SoftStop on the mullion side.



	No
16.5	780647
17.5	798249

# 7.4 Label



	No
Label indicating the operating sequence, diagram A	811486

IMO\_559\_EN\_v1 · 05 / 2022 · 87 Roto




Fig. 7.1: Figure for installation DIN right

		No
Label indicating the operating sequence, diagram C	Left	823251
	Right	823250



# 8 Brief instructions

# 8.1 Diagram A, A', K, K'

Summary of IMO 559

	Installation sequence	Note	Page reference	Timber	PVC
Sash	Crop the hardware components.		→ from page 98		
	Install the corner drives.	Align the cam vertically.	→ from page 100		
	Install the vertical centre lock on the espagnolette side.	Size-dependent	→ from page 100		
	Install the espagnolette.	Insert with the arrow pointing up.	→ from page 101		
	Install the centre locks.	CL, vertical on the mullion side (size-dependent)	→ from page 100		
		CL 130, horizontal at the top, bottom and on the mullion side	→ from page 101		
		CL, horizontal at the top and bottom (size-dependent)			
	Install the handle.		→ from page 102		
	Install the roller unit.	Timber: must not be pressed into the timber. Adapt the insertion torque if necessary.	→ from page 103		
	Install the stabilisation unit.	For SRW > 2110 mm, a second stabilisation unit is required.	→ from page 105		
	Install the control unit.	Alternatively: install the control unit with Soft function → from page 85.	→ from page 107		
		For SRW > 2110 mm, a fourth control unit is required.			
		Timber: must not be pressed into the timber. Adapt the insertion torque if necessary.			
	Install the centre closer with MUL locking cam.	Timber: must not be pressed into the timber. Adapt the insertion torque if necessary.	→ from page 109		
Frame	Install strikers.	Note the point of entry.	→ from page 120		
	Install the striker to prevent incorrect operation.		→ from page 129		
	Install the buffer.		→ from page 131		
	Install the roller track.	Timber: length: FIW - 2 mm	→ from page 134		
	Install the guide track.	Timber: length: (FIW - 2 mm)/2, screw down in the access area.	→ from page 136		
Joining the sash and frame	Install the guide track.	Timber: length: (FIW - 2 mm)/2, screw down in the fixed glazing area.	→ from page 136		
	Place the sash on the roller track.	Move the handle to the sliding position.	→ from page 138		
	Install the MUL strikers.		→ from page 144		
	Install the end stop with packer.				
	Install the stopper.		→ from page 152		
Final acceptance	Install the element.	Place supports under the threshold every 300 mm across its entire area.	→ from page 153		
		Max. permitted unevenness of the entire threshold: 3 mm.			
		We recommended that you place packers under the threshold across its entire area.			
	Adjust the hardware.		→ from page 158		
	Lubricate the hardware.		→ from page 163		
	Check the handle operating force.	Operating force ≤ 10 Nm			

 Subject to change.
 Roto Patio Inowa | 400
 IMO\_559\_EN\_v1 · 05 / 2022 · 89
 Ro

# 9 Installation

# 9.1 Processing instructions

#### Maximum sash sizes and weights

The specifications, application diagrams and component assignments which can be found in the hardware manufacturer's product-specific documents provide information on the maximum permitted sash sizes and weights. The component with the lowest permitted load bearing capacity determines the maximum permitted sash weight.

- Before using electronic data records and implementing them in window fabrication programs in particular, check that they match the specifications, application diagrams and component assignments.
- Never exceed the maximum permitted sash sizes and weights. If any points are unclear, contact the hardware manufacturer.

#### Specifications from profile manufacturers

The element manufacturer must comply with all specified system dimensions (e.g. gasket gap dimensions or locking distances).

They must continue to ensure and check this on a regular basis, especially when new hardware components are used for the first time, during production and on a continuous basis, up to and including element installation.



#### **INFO**

The hardware components are always designed in such a way that any system dimensions affected by the hardware can be adjusted. The hardware manufacturer shall not be liable for any additional expenses incurred if a deviation from these dimensions is not discovered until after the element has been installed.

#### Combining hardware

Burglar inhibiting elements need hardware which meets special requirements.

Elements for wet rooms and those for use in environments with aggressive, corrosive constituents in the air require hardware that meets special requirements.

The resistance of elements to wind loads when they are closed and locked depends on the individual design of the element. The hardware system is capable of handling wind loads specified by legislation and standards (for example in accordance with EN 12210 – especially test pressure P3).

Coordinate suitable hardware combinations and installation procedures in elements with the hardware manufacturer and profile manufacturer for the areas listed above, and conclude a separate agreement for them.



#### **INFO**

The hardware manufacturer's specifications on the combination of hardware (e.g. the use of additional scissor stays, the design of hardware for burglar-inhibiting elements, etc.) are binding.

#### Installation surfaces

The frame and sash grooves must be free from construction materials (such as plaster, gypsum). The sash groove must be free from welding residue to ensure an optimum supporting surface for the hardware components.

#### Specifications relating to installation and care



### **ATTENTION**

#### Sealing compounds that contain silicone may cause property damage.

Sealing compounds that contain silicone may considerably reduce the sealing effect near the threshold after three to five years.

Only use silicone-free sealing compounds to seal the threshold.

Remove excess sealing compound after installation.







#### **ATTENTION**

# Using incorrect cleaning agents and sealing compounds may cause property damage.

Cleaning agents and sealing compounds may damage the surfaces of components and gaskets.

- ▶ Do not use aggressive or flammable liquids, acidic cleaners or abrasive cleaners.
- Only use mild, pH-neutral cleaning agents that have been diluted.
- Apply a thin protective film to the components, for example using a cloth soaked in oil.
- Avoid aggressive vapours (e.g. produced by formic acid, acetic acid, ammonia, amine compounds, ammonia compounds, aldehyde, carbolic acid, chlorine, tannic acid) around the element.
- ▶ Do not use any acetic acid-crosslinking or acid-crosslinking sealing compounds or those with the aforementioned constituents as both direct contact with the sealing compound and its fumes can corrode the surface of the components.

#### 9.2 Screw connections



#### **DANGER**

#### Incorrectly installed or screwed-in hardware components present a risk of death.

Incorrectly installed and screwed-in hardware components may lead to hazardous situations and cause serious or fatal accidents.

- During installation and screwdriving work, observe the specifications provided by the profile manufacturer; contact the profile manufacturer if necessary.
- Use the recommended screws.
- Select the length of the screws according to the profiles used.
- Ensure that the hardware components are adequately secured; contact the screw manufacturer if necessary.



#### **ATTENTION**

#### Using incorrect screw material may cause property damage.

Using the wrong screws may damage the components.

- Only use galvanised zinc-plated and passivated steel screws.
- ▶ Use screws with additional sealing in more challenging climatic conditions.
- ▶ Use stainless-steel screws on stainless-steel components only.
- For aluminium components, use screws made of steel (coated with zinc-nickel or zinc flakes) or stainless steel.




#### **ATTENTION**

#### Improper screw fixings may cause property damage.

Improper screw fixings may damage the components and the element as a whole, and stop them from working properly.

- Unless stated otherwise, turn screws in straight.
- ▶ Tighten screw heads until they are flush with the surface.
- Do not over-tighten screws. Note the torque. Choose a torque that will not deform the hardware and profile. Define profile-specific torques on the basis of the demo assembly.
- Use the recommended screws.
- Select the length of the screws according to the profiles used.



#### 9.2.1 Overview



#### **WARNING**

#### Incorrect screw connections may pose a risk of death!

Hardware components can be pulled out of the sash if they are not screwed through a profile wall that is at least 6 mm thick in total or screwed down using rivet nuts.

Select the length of the screws so that they will hold in the aluminium profile. Alternatively, insert additional aluminium profiles.



#### **WARNING**

#### Incorrect screw connections may pose a risk of death!

Short screws will not reach the steel reinforcement and will therefore not hold.

Hardware components can be pulled out of the sash if they are not screwed into the steel reinforcement.

Select the length of the screws so that they will hold in the steel reinforcement.


#### **Timber**

Components	Quantity	Size	Diameter to be drilled	Drive
Roller unit	6	ST4.0 x	3.0	Not specified
Control unit	4	ST4.0 x	3.0	Not specified
Centre closer	4	ST4.0 x	3.0	Not specified
Stabilisation unit	4	ST4.0 x	3.0	Not specified
MUL striker / striker for anti-pushback function	2	ST4.0 x	3.0	Not specified
Striker / stop	2	ST4.0 x	3.0	Not specified
Activator / stopper	3	ST4.0 x	3.0	Not specified
Tilt protection device	2	ST4.0 x	3.0	Not specified
Roto Line handle	2	M5 x	10.0 / 12.0	Cross-head

#### **PVC**


Components	Quantity	Size	Diameter to be drilled	Drive
Roller unit	6	ST3.9 - 4.1 x	3.5	Not specified
Control unit	4	ST3.9 - 4.1 x	3.5	Not specified
Centre closer	4	ST3.9 - 4.1 x	3.5	Not specified
Stabilisation unit	4	ST3.9 - 4.1 x	3.5	Not specified
MUL striker / striker for anti-pushback function	2	ST3.9 - 4.1 x	3.5	Not specified
Striker / stop	2	ST3.9 - 4.1 x	3.5	Not specified
SEC striker	2	ST3.9 - 4.1 x	3.5	Not specified
Activator / stopper	3	ST3.9 - 4.1 x	3.5	Not specified
Tilt protection device	2	ST3.9 - 4.1 x	3.5	
Roto Line handle	2	M5 x	10.0 / 12.0	Cross-head

#### Specifications for selecting screws



- [A] Specifications relating to the countersink
- [B] Specifications relating to the screw head for selecting screws










#### **INFO**

Routing grooves or V-shaped grooves may damage the fixing when screwing it in and prevent it from releasing.

# 9.3 Drilling and routing dimensions

# 9.3.1 VT espagnolette




Drill holes for the handle's sprocket and lugs

- [1] Backset
- [2] Handle height

Drill hole  $\emptyset$  10: drilling depth = overlap height + 16 mm for countersunk screws (ISO 7046-1 M5 x ...)


Drill hole Ø 12: drilling depth = overlap height + 16 mm for countersunk screws (ISO 7046-1 M5 x ...)



Gearbox routing

- [1] Centre of gearbox
- [2] Hardware groove
- [3] Gearbox routing depth:
- BS + 17 (e.g. 30 + 17 = 47 mm)
- [4] Backset (BS)

# 9.3.2 VT espagnolette, lockable



Drill holes for Roto Line handle and profile cylinder for lockable espagnolettes

- [1] Backset
- [2] Handle height
- [3] Centre of gearbox
- [4] Min. routing depth

Drill holes: at the bottom for the square spindle and handle mount, at the top for the profile cylinder and profile cylinder escutcheon mount

Overlap height

Drill hole Ø 10: drilling depth = overlap height + 16 mm for countersunk screws (ISO 7046-1 M5 x ...)

Drill hole  $\emptyset$  12: drilling depth = overlap height + 16 mm for countersunk screws (ISO 7046-1 M5 x ...)

Routing for gearbox and lock casing


Routing: at the bottom for the gearbox, at the top for the lock casing

Gearbox / lock casing routing depth:

BS 25 = 42 mm

BS 30 = 47 mm

# 9.3.3 External recessed grip



Recessed grip routing


Routing depth = 10 mm

- [1] Backset
- [2] Handle height



# 9.3.4 Operating sequence control cam






Routing for cam

Routing depth = through adapter profile [1]

F = Operating sequence control cam in open sliding position

# 9.3.5 Striker H, can be routed in





Routing for striker H, can be routed in


Routing depth = 10 mm

[1] Cam (VT espagnolette)



# 9.3.6 Rubber buffer






Create a stepped hole with a spade drill.

- 1. Drill to a depth of 6 mm with  $\emptyset$  22 mm.
- 2. Drill to a depth of 13 mm with  $\emptyset$  12.5 mm.

# 9.3.7 Tilt protection device

1. Notch the adapter profile (if present) on the sash in the area of the corner drive.







# 9.4 Sash

# 9.4.1 Force-fit connection

Coupleable hardware components always require a force-fit connection.





Assignment	Description
[1]	Component A
[2]	Screw guide with clamp
[3]	Component B
[4]	Component A toothed segment
[5]	Component B toothed segment
[6]	Screw

Force-fit connections are formed by screwing down components A and B so that forces and movements are transferred without loss.



# **INFO**

All coupleable components are delivered attached in the centre.

Roto

# 9.4.2 Cropping the hardware components



#### **ATTENTION**

#### Incorrect cropping methods may result in property damage.

Do not insert the hardware components into the sash before they have been cropped. The screw guide engages and can be destroyed when it is removed.


Only lay out the hardware components and do not insert them into the sash before they have been cropped.

The following hardware components are cropped:

- Espagnolette
- Centre locks


# Cropping with a pneumatic punch (hole punching)

Hardware components are delivered 10 mm longer than the nominal dimension.



Assignment	Description
[1]	Hardware delivery state
[2]	Hardware, cropped

- 1. Place the hardware component in the required position.
- 2. Mark the length on the hardware component.
- 3. Insert the hardware component [1] into the pneumatic punch [2].



- 4. Align the hardware component.
- 5. Crop the hardware component.




Installation sequence



# 9.4.3 Installation sequence

# 9.4.3.1 Diagram A



- [1] Corner drives
- [2] Espagnolette extension (size-dependent)
- [3] Espagnolette
- [4] Centre locks CL 130, horizontal at the top and bottom
- [5] Centre locks, horizontal at the top and bottom (size-dependent)
- [6] Centre locks CL 130, vertical on the mullion side
- [7] Centre locks, vertical on the mullion side (size-dependent)



# **INFO**

After installation, break the centre fixing on the espagnolette by turning the handle 180°.


Turn the handle to the open sliding position.

#### 9.4.4 Corner drive



# Installing the corner drive

1. Insert the corner drive with vertical cam position [1] and secure with two screws [2].



 After all of the connector components have been installed, screw down the corner drives with a further two screws [3]. → 9.4.1 "Force-fit connection" from page 97



# **INFO**

Diagram C / C' – second opening sash: insert the corner drives (with E cam) horizontally on the locking side with cam position and secure with screws.

# 9.4.5 Centre locks

### 9.4.5.1 Centre lock, vertical



# Installing the vertical centre lock

1. Insert the centre lock on the mullion side and create a force-fit connection → 9.4.1 "Force-fit connection" from page 97.



# 9.4.5.2 Centre lock, horizontal



# Installing the horizontal centre lock

1. Insert the centre lock at the bottom and top on the locking side and create a force-fit connection → 9.4.1 "Force-fit connection" from page 97.


# 9.4.6 VT espagnolette



# Installing the VT espagnolette

 Place the espagnolette in the required position, mark the length on one side, remove and crop → 9.4.2 "Cropping the hardware components" from page 98.

Insert the espagnolette.
 Create a force-fit connection → 9.4.1 "Force-fit connection" from page 97.






# 9.4.7 Handle and recessed grip

# Installing the handle and recessed grip

- 1. Move the handle [1] to the 90° position → 12.1.1 "Roto Patio Inowa" from page 160.
- 2. Turn the escutcheon cover [2] in order to expose the screw holes.



- 3. Insert the handle into the sash [3].
- 4. Insert the recessed grip into the sash on the opposite side.
- 5. Screw the recessed grip through the handle with two screws [4].
- Turn the escutcheon cover in order to expose the screw holes.



#### 9.4.8 Roller unit



#### **INFO**

The roller unit must not be pushed into the timber. Adapt the torque if necessary.

For the roller unit, ensure that the adjusting screw [1] is facing towards the handle when installed.



# Positioning the drilling jig






#### **ATTENTION**

# Improper drilling work may cause property damage.

An incorrect handle position and incorrect alignment of the drilling jig damage the sash during drilling.







For profiles with just one mounting surface, align the drilling jig so that it is parallel with this surface when drilling.

Refer to the installation drawing for the position → from page 154.




















IMO\_559\_EN\_v1 · 05 / 2022 · 103




# Installing roller units

1. Drill six holes.


Drill [1]: timber Ø 3.0; PVC Ø 3.5 Shown: diagram A, DIN L



2. Insert the roller unit [2] and fasten with outer screws [3].



3. Move the handle to the closed position. Fasten the roller unit with two inner screws [4].



# 9.4.9 Stabilisation unit



# **ATTENTION**


# Improper drilling work may cause property damage.


An incorrect handle position and incorrect alignment of the drilling jig damage the sash during drilling.


The handle must be in the open sliding position [1].


Attach the drilling jig to the control cam [2].

Refer to the installation drawing for the position  $\rightarrow$  from page 154.










# Installing the stabilisation unit


1. Drill four holes.

Drill [1]: Ø 3.0

Shown: diagram A, DIN L



2. Insert the stabilisation unit [2] and fasten with screws [3].





#### 9.4.10 Control unit



#### **INFO**

The control unit must not be pushed into the timber. Adapt the torque if necessary.

For control units with Soft function, ensure that the additional control roller [1] is facing towards the centre of the sash when installed .



#### Positioning the drilling jig





#### **ATTENTION**

# Improper drilling work may cause property damage.

An incorrect handle position and incorrect alignment of the drilling jig damage the sash during drilling.

► The handle must be in the open sliding position [1].


Attach the drilling jig to the cam [2].

For profiles with just one mounting surface, align the drilling jig so that it is parallel with this surface when drilling.


Refer to the installation drawing for the position → from page 154.




















IMO\_559\_EN\_v1 · 05 / 2022 · 107


# Installing the control unit

1. Drill four holes.

Drill [1]: timber Ø 3.0; PVC Ø 3.5 Shown: diagram A, DIN L

2. Insert the control unit [2] and fasten with screws [3].







#### 9.4.11 Centre closer



#### **INFO**

The centre closer must not be pushed into the timber. Adapt the torque if necessary.

#### Positioning the drilling jig






#### **ATTENTION**

# Improper drilling work may cause property damage.

An incorrect handle position and incorrect alignment of the drilling jig damage the sash during drilling.





Outward running sashes: position the drilling jig so that the side with the Ø 14.0 drill hole [2] is facing the handle.



Attach the drilling jig to the control cam [3].

Refer to the installation drawing for the position  $\rightarrow$  from page 154.




#### INFO


For both RC 2 and diagram C, drill the holes for the centre closers for anti-pushback function .








2









#### Installing centre closers


1. Drill one hole.

Drill [1]: Ø 14.0

Drill four holes.

Drill [2]: timber Ø 3.0; PVC Ø 3.5

Shown: diagram A, DIN L




2. Move the handle to the closed position.

Insert the centre closer so that the MUL locking cam mount is facing the drill hole [3] on the outer


side of the sash.

Fasten with four screws [4].



3. Fasten the MUL locking cam at a distance of 2 mm from the centre closer.

Tool: size 8 open-end spanner / size 4 hex key





## 9.4.12 Centre closer for anti-pushback function



#### **INFO**

Diagram A / C: install right components for DIN L; install left components for DIN R.

Diagram C': install left components for DIN L; install right components for DIN R.

The centre closer must not be pushed into the timber. Adapt the torque if necessary.

#### Positioning the drilling jig





#### **ATTENTION**

# Improper drilling work may cause property damage.

An incorrect handle position and incorrect alignment of the drilling jig damage the sash during drilling.


- ► The handle must be in the open sliding position.
- Inward running sashes: position the drilling jig so that the side with the Ø 14.0 drill hole [1] is facing away from the handle.
- ▶ **Outward running sashes**: position the drilling jig so that the side with the Ø 14.0 drill hole [1] is **facing** the handle.

Attach the drilling jig to the control cam [2].


Refer to the installation drawing RC or diagram C for the position  $\rightarrow$  from page 154.























### Installing the centre closer for anti-pushback function


1. Drill one hole.

Drill [1]: Ø 14.0


Drill one hole.


Drill [2]: timber Ø 3.0; PVC Ø 3.5

Shown: diagram A, DIN L




2. Install the centre closer → from page 109.






3. Insert the centre closer so that the MUL locking cam mount is facing the drill hole [3] on the outer side of the sash.

Fasten with four screws [4].



4. Fasten the pin for anti-pushback function [5] at a distance of 2 mm from the centre closer.

Tool: size 3 hex key





#### 9.4.13 Rubber buffer



#### **INFO**

Timber: install the rubber buffer in the frame → 9.5.8 "Rubber buffer" from page 137.

### Installing rubber buffers


 Install the profile-related cover on the mullion side. Ensure that the guide track and roller track are running smoothly.





#### **INFO**

Place pressure-proof packers underneath the cover at the top and bottom in the hatched area for installing the rubber buffers. Ensure that the cam on the corner drive is running smoothly.




2. Drill two holes  $\emptyset$  10 mm for rubber buffers at the top and bottom of the cover.




#### **INFO**

The dimension X for the drill hole is profile-related.




3. Insert the rubber buffer [1].



## 9.4.14 Diagram C / C' - faceplate component positions

#### PVC



[1] Sash rebate edge; [A] First opening sash; [B] Second opening sash

Striker (G1 = striker to prevent incorrect operation)

Buffer

Operating sequence control set: anti-lifting device (X1), stop (X2), bolt (2)

## Anti-lifting device and stop, first opening sash, on the espagnolette side


SRH / mm	X1	X2
2000 - 2200	89	1552
2201 - 2400	89	1552
2401 - 2600	89	1596
2601 - 2800	89	1596
2801 - 3000	89	1596
3001 - 3200	89	1596
3201 - 3400	89	1596
3401 - 3600	89	1596

## Striker and buffer, second opening sash, on the espagnolette side

SRH / mm	G1	G2	G3	G4	G5	G6	P1	P2
2000 - 2200	51	686	1356	SRH-48	_	_	150	SRH-160
2201 - 2400	51	686	1356	SRH-48	-	-	150	SRH-160
2401 - 2600	51	686	1756	SRH-48	-	_	150	SRH-160
2601 - 2800	51	686	1756	SRH-48	_	_	150	SRH-160
2801 - 3000	51	686	1756	SRH-648	SRH-48	_	150	SRH-160
3001 - 3200	51	686	1756	SRH-848	SRH-48	-	150	SRH-160
3201 - 3400	51	686	1756	SRH-1048	SRH-48	-	150	SRH-160
3401 - 3600	51	686	1756	SRH-1248	SRH-648	SRH-48	150	SRH-160



#### Timber



[1] Sash rebate edge; [A] First opening sash; [B] Second opening sash

☐ Striker

Buffer

Operating sequence control set: anti-lifting device (X1), stop (X2), bolt (2)

## Stop, first opening sash, on the espagnolette side

SRH / mm	X2
2000 - 2200	1552
2201 - 2400	1552
2401 - 2600	1596
2601 - 2800	1596
2801 - 3000	1596
3001 - 3200	1596
3201 - 3400	1596
3401 - 3600	1596

## Striker, buffer and anti-lifting device, second opening sash, on the espagnolette side


SRH / mm	G1	G2	G3	G4	G5	G6	P1	P2	X1
2000 - 2200	51	686	1356	SRH-48	-	_	150	SRH-160	1526
2201 - 2400	51	686	1356	SRH-48	_	_	150	SRH-160	1526
2401 - 2600	51	686	1756	SRH-48	_	_	150	SRH-160	1570
2601 - 2800	51	686	1756	SRH-48	_	_	150	SRH-160	1570
2801 - 3000	51	686	1756	SRH-648	SRH-48	_	150	SRH-160	1570
3001 - 3200	51	686	1756	SRH-848	SRH-48	_	150	SRH-160	1570
3201 - 3400	51	686	1756	SRH-1048	SRH-48	_	150	SRH-160	1570
3401 - 3600	51	686	1756	SRH-1248	SRH-648	SRH-48	150	SRH-160	1570

## 9.4.15 Striker, diagram C



#### 9.4.15.1 Drilling the holes for striker, diagram C

## Dimensional drawing in open sliding position



[1] Striker, diagram C [2] Locking cam


## 9.4.15.2 Installing the diagram C striker

⇒ Note the drilling specifications → 9.3.4 "Operating sequence control cam" from page 95.

1. Fasten the diagram C striker [1] with two screws [2] in the slots.

Check the position and fasten with an additional two screws [3].








# 9.4.16 Installing the buffer

#### Timber

1. Fasten each buffer with four screws.



## PVC


See installation of the buffer on the frame → from page 131.



### 9.4.17 Operating sequence control

Alternatively: position of the components according to the installation diagram C – faceplate components **>** *from page 114*.


#### **PVC**



#### Installing the operating sequence control

- 1. Move the handle of the second opening sash to the closed sliding position.
- 2. Attach the bolt at the position provided [1] on the espagnolette of the second opening sash. The marking (red) points up.


Fasten with one screw [2].



3. Push the first opening sash shut until the lower edge [A] of the bolt can be transferred to the first opening sash.

Open the first opening sash again and pre-position the stop [3] on the first opening sash with two screws [4] in slots, at an offset of 2 mm from the lower edge of the bolt.


Check the position and fasten with an additional two screws [5].






4. Push the first opening sash shut until the top edge [B] of the lowest striker [6] can be transferred to the first opening sash.

Open the first opening sash again and fasten the anti-lifting device [7] to the first opening sash with two screws, at an offset of 1 mm from the top edge of the striker.




#### Timber



#### Installing the operating sequence control

- 1. Move the handle of the second opening sash to the closed sliding position.
- 2. Attach the bolt at the position provided [1] on the espagnolette of the second opening sash. The marking (red) points up.

Fasten with one screw [2].




3. Push the first opening sash shut until the lower edge [A] of the bolt can be transferred to the first opening sash.

Open the first opening sash again and pre-position the stop [3] on the first opening sash with two screws [4] in slots, at an offset of 2 mm from the lower edge of the bolt.

Check the position and fasten with an additional two screws [5].

Push the first opening sash shut until the lower edge [B] of the stop can be transferred to the second opening sash.


Open the first opening sash again and fasten the anti-lifting device [6] to the second opening sash with two screws, at an offset of 2 mm from the stop.



### 9.5 Frame

## 9.5.1 Striker positions

#### **Standard**





Striker / MUL striker

■ Buffer

#### Striker, screw-on, on the espagnolette side

SRH / mm	G1	G2	G3	G4	G5	G6
2000 - 2200	86	721	1391	SRH-13	-	-
2201 - 2400	86	721	1391	SRH-13	-	-
2401 - 2600	86	721	1791	SRH-13	-	-
2601 - 2800	86	721	1791	SRH-13	-	-
2801 - 3000	86	721	1791	SRH-613	SRH-13	-
3001 - 3200	86	721	1791	SRH-813	SRH-13	-
3201 - 3400	86	721	1791	SRH-1013	SRH-13	-
3401 - 3600	86	721	1791	SRH-1213	SRH-613	SRH-13

# Striker, can be routed in, on the espagnolette side

SRH / mm	<b>G</b> 1	G2	G3	G4	G5	G6
2000 - 2200	94	718	1388	SRH-16	-	_
2201 - 2400	94	718	1388	SRH-16	-	_
2401 - 2600	94	718	1788	SRH-16	_	_
2601 - 2800	94	718	1788	SRH-16	_	_
2801 - 3000	94	718	1788	SRH-616	SRH-16	_
3001 - 3200	94	718	1788	SRH-816	SRH-16	_
3201 - 3400	94	718	1788	SRH-1016	SRH-16	_
3401 - 3600	94	718	1788	SRH-1216	SRH-616	SRH-16


## MUL striker, on the mullion side

SRH / mm	M1	M2	M3	M4	M5
2000 - 2200	219	SRH-949	SRH-149	-	-
2201 - 2400	219	SRH-1149	SRH-149	-	_
2401 - 2600	219	SRH-1349	SRH-749	SRH-149	_
2601 - 2800	219	SRH-1549	SRH-749	SRH-149	_
2801 - 3000	219	SRH-1749	SRH-949	SRH-149	_
3001 - 3200	219	SRH-1949	SRH-1149	SRH-149	-
3201 - 3400	219	SRH-2149	SRH-1149	SRH-149	_
3401 - 3600	219	SRH-2349	SRH-1749	SRH-749	SRH-149

# Buffer in conjunction with striker, screw-on [1] / can be routed in [2]

SRH / mm	P1 [1]	P1 [2]	P2 [1]	P2 [2]
2000 - 3600	185	184	SRH-125	SRH-106

#### Security



- SEC striker (on the handle side), SEC MUL striker (on the mullion side)
- Striker for anti-pushback function
- SEC striker to prevent incorrect operation
- Buffer

## SEC striker, screw-on, on the espagnolette side

SRH / mm	G1	G2	G3	G4	G5	G6
2000 - 2200	86	721	1391	SRH-13	-	-
2201 - 2400	86	721	1391	SRH-13	-	-
2401 - 2600	86	721	1791	SRH-13	_	-
2601 - 2800	86	721	1791	SRH-13	-	-
2801 - 3000	86	721	1791	SRH-613	SRH-13	-
3001 - 3200	86	721	1791	SRH-813	SRH-13	-
3201 - 3400	86	721	1791	SRH-1013	SRH-13	-
3401 - 3600	86	721	1791	SRH-1213	SRH-613	SRH-13

# SEC MUL striker, on the mullion side

SRH / mm	M1	M2	M3	M4	M5	M6	M7
2000 - 2100	219	SRH-1279	SRH-679	SRH-149	_	_	_
2101 - 2300	219	SRH-1479	SRH-1079	SRH-679	SRH-149	_	_
2301 - 2500	219	SRH-1679	SRH-1079	SRH-679	SRH-149	_	_
2501 - 2700	219	SRH-1879	SRH-1279	SRH-679	SRH-149	_	_
2701 - 2900	219	SRH-2079	SRH-1679	SRH-1279	SRH-679	SRH-149	_
2901 - 3100	219	SRH-2279	SRH-1879	SRH-1279	SRH-679	SRH-149	_
3101 - 3300	219	SRH-2479	SRH-1879	SRH-1279	SRH-679	SRH-149	_
3301 - 3500	219	SRH-2679	SRH-2279	SRH-1879	SRH-1279	SRH-679	SRH-149
3501 - 3600	219	SRH-2879	SRH-2479	SRH-1879	SRH-1279	SRH-679	SRH-149

# Striker for anti-pushback function, on the mullion side

SRH / mm	R1	R2
2000 - 2100	349	SRH-279
2101 - 2300	349	SRH-279




SRH / mm	R1	R2
2301 - 2500	349	SRH-279
2501 - 2700	349	SRH-279
2701 - 2900	349	SRH-279
2901 - 3100	349	SRH-279
3101 - 3300	349	SRH-279
3301 - 3500	349	SRH-279
3501 - 3600	349	SRH-279

# Buffer in conjunction with striker, screw-on [1] / can be routed in [2]

SRH / mm	P1 [1]	P1 [2]	P2 [1]	P2 [2]
2000 - 3600	185	184	SRH-125	SRH-106

## Diagram C / C'

#### Standard



[A] First opening sash; [B] Second opening sash


Striker for anti-pushback function

## MUL striker, on the mullion side

SRH / mm	M1	M2	M3	M4	M5
2000 - 2200	219	SRH-949	SRH-149	_	-
2201 - 2400	219	SRH-1149	SRH-149	-	_
2401 - 2600	219	SRH-1349	SRH-749	SRH-149	_
2601 - 2800	219	SRH-1549	SRH-749	SRH-149	_
2801 - 3000	219	SRH-1749	SRH-949	SRH-149	_
3001 - 3200	219	SRH-1949	SRH-1149	SRH-149	_
3201 - 3400	219	SRH-2149	SRH-1149	SRH-149	_
3401 - 3600	219	SRH-2349	SRH-1749	SRH-749	SRH-149

#### Striker for anti-pushback function, on the mullion side

SRH / mm	R
2000 - 2200	SRH-1079
2201 - 2400	SRH-1279
2401 - 2600	SRH-1479
2601 - 2800	SRH-1679
2801 - 3000	SRH-1879
3001 - 3200	SRH-2079
3201 - 3400	SRH-2279
3401 - 3600	SRH-2479



- [1] Striker, screw-on (G1 [1] G6)
- [2] Striker to prevent incorrect operation (G1 [2])
- [3] Striker, can be routed in, for timber (G1 G6)
- [4] MUL striker (M1 M5)
- [5] SEC MUL striker (M1 M7)
- [6] Striker for anti-pushback function (R)
- [7] Buffer (P1 P2)
- [8] Roller track



#### INFO

- Align the screw-on striker with the point of entry.
- For the striker, which can be routed in, observe the routing drawing → 9.3.5 "Striker H, can be routed in" from page 95. Insert the striker, which can be routed in, in the centre of the routing.
- Align the MUL striker and the striker for anti-pushback function in the centre.
- Dimensions M1 M4 apply to the coverage between the guide track and control unit of ≥ 9 mm.
- Pay attention to the profile assessment.



## 9.5.2 Striker, screw-on

## 9.5.2.1 Preparing the frame for the striker, screw-on




## **INFO**

The marker can be used for sashes that run inward or outward.


In its delivery state, it is suitable for:

- DIN L running inward
- DIN R running outward




## Preparing the marker

1. Unscrew the tip of the marker [1].



IMO\_559\_EN\_v1 · 05 / 2022 · **125** 

2. Turn the marker [2] and reinsert the tip of the marker on the rear.



3. Tighten the tip of the marker.



#### **INFO**

The marker is now suitable for:

- DIN R running inward
- DIN L running outward

## Marking a position


1. Place the markers for strikers, screw-on, [1] on the espagnolette side on each locking cam [2].




#### **INFO**

When using the marker to determine the correct drill markings, move the handle to the open position.

The correct position is ensured using a magnet in the marker.










2. Close the sash with the marker fitted.


View without sash and hardware:

When closing the sash, the tips of the markers create two marks in the frame profile. These mark the correct drilling position for the striker in question.



# 9.5.2.2 Drilling the holes for the striker

## Dimensional drawing in open sliding position



[1] Striker, screw-on[2] Locking cam

 For the position of the strikers, see the installation drawing → from page 154. Alternatively: with marking jig.




#### **INFO**

Predrill the frame profile with steel core.

Drill:  $2 \times \emptyset 3.5 \text{ mm}$ ; depth = X


Drill:  $2 \times \emptyset 4.5$  mm; depth = X



# 9.5.2.3 Installing the striker

1. Fasten each striker [1] with two screws [2].








## 9.5.3 Striker to prevent incorrect operation

#### 9.5.3.1 Drilling the holes for the striker to prevent incorrect operation

## Dimensional drawing in open sliding position



- [1] Striker to prevent incorrect operation
- [2] Locking cam

1. For the position of the striker to prevent incorrect operation, see the installation drawing.




#### **INFO**

Predrill the frame profile with steel core.

Drill:  $2 \times \emptyset 3.5$ ; depth = X

Drill holes.

Drill:  $2 \times \emptyset 4.5$ ; depth = Y



#### 9.5.3.2 Installing the striker to prevent incorrect operation


1. Secure the striker to prevent incorrect operation [1] with two screws [2].



## **INFO**

Note the drilling specifications → 9.5.3.1 "Drilling the holes for the striker to prevent incorrect operation" from page 129.








#### 9.5.4 Buffer

## 9.5.4.1 Drilling the holes for the buffer

# Dimensional drawing in open sliding position



- [1] Striker
- [2] Locking cam on the corner drive
- [3] Buffer



#### **INFO**

The version on the bottom is mirror-inverted.

 For the position of the buffer, see the installation drawing → from page 154.




#### **INFO**

Predrill the frame profile with steel core.

Drill:  $2 \times \emptyset 3.5 \text{ mm}$ ; depth = X


Drill:  $2 \times \emptyset 4.5$  mm; depth = X



# 9.5.4.2 Installing the buffer

1. Fasten each buffer [1] with two screws [2].








## 9.5.5 Striker for anti-pushback function

## Installing the striker for anti-pushback function

 Place the drilling jig for striker for anti-pushback function [1] flush against the frame profile at the height of the pin [2]. For better guidance, move the sash with pin fitted in the direction of the arrow.
 Drill the holes [3].

Drill: timber Ø 3.0; PVC Ø 3.5






2. Drill the hole [4]. Drill: Ø 12.5 mm




## **INFO**


Refer to the system-specific profile assessment for the drilling depth.



3. Secure the striker for anti-pushback function [5] with two screws [6].



4. Clip the cover cap [7] onto the striker for antipushback function.



#### 9.5.6 Roller track



#### **INFO**

Pay attention to the profile assessment.

- Adapt the width of the roller track under your own responsibility.
- Seal the roller track properly under your own responsibility. Prevent water from entering underneath the roller track.
- Fit a water drain under your own responsibility so that water is drained away to the outside in a controlled manner.
- Ensure that the roller track is securely attached.
- Protect the roller track against contamination and additional surface treatment.


#### Version with continuous roller track

Diagram A' is shown here.


1. Cut the roller track [1] to size.

X = FIW - 2 mm

Y = profile width



2. Place the roller track on the threshold [2] and press down firmly into the threshold groove [3].



#### Version with split roller track

Diagram C' is shown here.





1. Cut the roller tracks [1] to size.




#### **INFO**

Ensure that the drainage holes are located at least 50 mm away from the edge.


Cut both roller tracks to the same length.

X = (FIW - 2 mm)

Y = profile width




2. Remove the roller track grooves in the joint area.



3. Attach a sealing strip [2] as a connection element between the two roller tracks.

Place the roller tracks on the threshold [3] and press down firmly into the threshold groove [4].



#### 9.5.7 Guide track



#### **ATTENTION**

#### Protruding screw heads may cause property damage.

Protruding screw heads in the area of the activator when opening the sash can damage the control unit.

1. Do not screw the guide track in the area of the activator.



#### **INFO**


- Pay attention to the system-specific profile assessment.
- Seal the guide track properly under your own responsibility. Prevent water from entering underneath the guide track.
- Ensure that the guide track is securely attached.
   Adhere to a screw spacing of max. 300 mm.

### Preparing the guide track - version with split guide track

1. Cut the guide track for the access area to size and predrill it.

X = (FIW - 2 mm)/2






2. Cut the guide track for the fixed glazing area to size and predrill it.


X = (FIW - 2 mm)/2





## Installing the guide track in the access area - version with split guide track

1. Insert the guide track into the frame in the access area and fasten with screws [1] (screws spaced max. 300 mm apart).







#### **INFO**

Only install the guide track in the fixed glazing area once the sash has been inserted.

#### 9.5.8 Rubber buffer



## Installing rubber buffers


1. Insert the rubber buffer [1].



#### **INFO**

Note the drilling specifications → from page 96.





# 9.6 Joining the sash and frame



#### **CAUTION**

#### Heavy loads pose a risk of injury.

Lifting and carrying heavy loads in an uncontrolled manner may lead to physical injury.

- Transport and installation must be carried out by at least two people.
- ▶ Use transportation means. → 15 "Transport" from page 168
- Note the applicable accident prevention regulations.



#### **ATTENTION**

#### Heavy loads may cause property damage.

Lifting and carrying heavy loads in an uncontrolled manner may lead to property damage.

- Transport and installation must be carried out by at least two people.
- Use transportation means. → 15 "Transport" from page 168
- Do not rest sashes on the rollers.

#### 9.6.1 Inserting the sash



#### **WARNING**

#### An unsecured sash may pose a risk of death!

The sash may fall during installation if it is not securely connected to the frame.

Secure the sash to prevent it from falling, e.g. by using two people.



#### **INFO**

- Pay attention to the system-specific profile assessment.
- Seal the guide track properly under your own responsibility. Prevent water from entering underneath the guide track.
- Ensure that the guide track is securely attached. Adhere to a screw spacing of max. 300 mm.

#### Version with split guide track, inserting the sash at the bottom

The guide track is installed in the access area.

The guide track for the fixed glazing area is prepared.


1. Move the handle to the open sliding position



2. In front of the fixed glazing area, insert the sash at the bottom of the frame and position the roller unit on the roller track without impact.


For roller tracks with just one wall, ensure that the roller unit rollers are not set down next to the roller track.

Check that the roller unit rollers are correctly positioned on the roller track by pushing the sash.





3. Push the sash onto the roller track in front of the access area in a controlled manner until all control units are located in the guide track that is already installed.




4.




Move the handle to the closed position

5. Insert the prepared guide track into the frame in the fixed glazing area and fasten with screws (screws spaced max. 300 mm apart).



# Version with continuous guide track, inserting the sash at the bottom

1. Cut the guide track to size.





2. Move the handle to the open sliding position




3. In front of the access area, insert the sash at the bottom of the frame and position the roller unit on the roller track without impact.


For roller tracks with just one wall, ensure that the roller unit rollers are not set down next to the roller track.

Check that the roller unit rollers are correctly positioned on the roller track by pushing the sash. Position the guide track on the control units at the top.

Tilt the sash with guide track fitted inwards in a controlled manner at the top until the guide track can be installed in the frame groove provided.




4. Fasten the guide track with screws [1] (screws spaced max. 300 mm apart).



### Version with continuous guide track, inserting the sash at the top

1. Cut the guide track to size.



#### Joining the sash and frame

Inserting the sash




2. Fasten the guide track with screws [1] (screws spaced max. 300 mm apart).

Move the handle to the open sliding position



In front of the access area, insert the sash at the top of the frame until the control units engage in the guide track.



3. Tilt the sash inwards in a controlled manner at the bottom until the roller units are positioned vertically on the roller track.

For roller tracks with just one wall, ensure that the roller unit rollers are not set down next to the roller track.

Check that the roller unit rollers are correctly positioned on the roller track by pushing the sash.




#### 9.6.2 MUL striker


# 9.6.2.1 Drilling the holes for the MUL striker

1. Place the drilling jig for MUL striker [1] flush against the frame profile at the height of the locking cam [2]. Mark the position of the drilling iig.





Drill the holes [3].Drill: timber Ø 3.0; PVC Ø 3.5





#### 9.6.2.2 Installing the MUL striker


1. Secure the MUL striker [1] with two screws [2].




## **INFO**

Note the drilling specifications → 9.6.2.1 "Drilling the holes for the MUL striker" from page 142.





2. Clip the cover cap [3] onto the MUL striker.






#### 9.6.3 SEC MUL striker


## 9.6.3.1 Drilling the holes for the MUL striker

 Place the drilling jig for MUL striker [1] flush against the frame profile at the height of the locking cam [2]. Mark the position of the drilling jig.





2. Drill the holes [3]. Drill: timber Ø 3.0; PVC Ø 3.5





## 9.6.3.2 Installing the SEC MUL striker


1. Secure the SEC MUL striker [1] with four screws [2].



#### **INFO**

Note the drilling specifications .

Clip the cover cap [3] onto the SEC MUL striker.



## 9.6.4 Activator and packer


- ⇒ The control unit with soft function comes assembled in its delivery state (= untensioned).
- ⇒ The element is glazed.

## 9.6.4.1 Determining the quantity of packers

1. Calculate or refer to the profile assessment for the quantity of packers required [1].

Quantity of packers = (Y - 38) / 2

Maintain a distance of  $27.5\pm1$  mm between the highest point of the activator [2] and the control unit supporting surface.



#### 9.6.4.2 Diagram A

## Installing the activator with / without packer(s) on the espagnolette side


1. Connect the packers to the activator using locating aids. Ensure that the slots are aligned.

Predrill a hole for the screw [3] (for dimension X, see the profile assessment). Slightly tighten the activator with one screw to position it (for dimension Y, see the profile assessment) so that the activator can still be moved.

Close the sash slowly and open it again to move the activator into the installation position.

Predrill the holes for screws [4].

Fasten the activator with three screws.



#### Installing the activator with / without packer(s) on the mullion side

1. Connect the packers to the activator using locating aids. Ensure that the slots are aligned.

Predrill a hole for the screw [1] (for dimension Z, see the profile assessment). Slightly tighten the activator with one screw to position it (for dimension Y, see the profile assessment) so that the activator can still be moved.

Open the sash fully and close it again to move the activator into the installation position.


Predrill the holes for screws [2].

Fasten the activator with three screws.




#### **INFO**

Control unit with SoftOpen and SoftStop on the mullion side: if the sash is to be prevented from coming into contact with the buffer, move the screw position by the required dimension U. Tension the control unit with SoftStop → from page 148. Open the sash fully. Transfer the position of the sash installation surface [3] to the roller track. Install the end stop [4] offset by 15 mm towards the sash.





#### 9.6.4.3 Diagram C



- [A] First opening sash
- [B] Second opening sash
- [C] Centre of guide groove in the guide track
- 1. Connect the packers to the activator using locating aids. Ensure that the slots are aligned.

Predrill a hole for the screw [1] (for the first opening sash to dimension W, for the second opening sash to dimension Z, see profile assessment). Slightly tighten every activator with one screw each to position them (for dimensions X and Y, see the profile assessment) so that the activator can still be moved.

Close the second opening sash [B] slowly and open it again to move the activator into the installation position. Predrill the holes for screws [2].

Secure with three screws.

Close the second opening sash and move the handle to the closed position.

Close the first opening sash [A] slowly and open it again to move the activator into the installation position.

Predrill the holes for screws [3].

Secure with three screws.

## 9.6.5 Tensioning the control unit with soft function




#### **CAUTION**

#### Risk of injury caused by tensioning the control unit with soft function by hand.

When installing the control unit with soft function, tensioning by hand may cause injuries due to sharp edges.

- 1. Only tension the control unit with soft function using a tensioning tool.
- 1. Mount the tensioning tool recess [1] in the activator bolt [2].

Push the element shut slowly until the connector [3] on the tensioning tool engages in the control unit with soft function.



2. Open up the element slowly to activate the soft function. The connector on the tensioning tool will be released automatically.



## 9.6.6 Tilt protection device



#### **DANGER**

#### The uncontrolled tilting of sashes with aspect ratios > 2:1 poses a risk of death!

Uncontrolled tilting may cause sashes with aspect ratios > 2:1 to jump out of the guide track. This many lead to hazardous situations and cause serious or fatal accidents.

- ▶ The roller track must have two walls → 3.6 "Dimensions of the roller track" from page 28.
- Install the tilt protection device (only without control unit with Soft function) → 3.7 "Dimensions of the tilt protection device" from page 28.



#### **ATTENTION**

#### Premature installation may cause property damage.

If the tilt protection device is installed before the sash and frame are joined, this can damage the installed hardware.

1. Only install the device once the sash and frame have been joined.




#### **INFO**

Example diagram.


Drilling patterns are profile-related (available upon request).

#### Preparing the drilling jig

## For use on the espagnolette side



#### For use on the mullion side



- 1. Detach the drilling plate [1] from the stop [2] by loosening the screw [3].
- 2. Turn the drilling plate 180°.
- 3. Fasten the drilling plate to the stop with one screw.

IMO\_559\_EN\_v1 · 05 / 2022 · 149

## Drilling the holes for the tilt protection device

1. Open the sash.

Move the handle to the closed position . Loosen the screw [1] on the drilling plate [2]. Position the drilling jig on the corner of the sash at the top on the espagnolette side.


- Inward running sashes: position the drilling jig so that the side with the drill holes is facing away from the handle.
- Outward running sashes: position the drilling jig so that the side with the drill holes is facing the handle.

Push the drilling plate up until it reaches the stop on the guide track [3].

Fasten the drilling plate with a screw again.


Align the drilling jig so that it is centred relative to the hardware and drill through two walls.

Drill: 2 x Ø 3.5



#### Installing the tilt protection device


- ⇒ The adapter profile (if present) is routed → from page 96.
- ⇒ The adapter profile stops flush with the sash rebate.
- 1. Fasten the tilt protection device with two screws through two walls.






## 9.6.7 End stop with packer

1. Adapt the end stop packer and, if necessary, the end stop on a profile-related basis.




2. Place the end stop packer [1] on the roller track [2] and fasten with screws.



3. Drill the holes for the end stop.[A]: Ø 8.0+0.2 (1x)[B]: predrill Ø 3.0 (1x)



4. Install the rubber buffer [3] in the end stop [4], position it on a packer, and fasten with a screw [5].



## 9.6.8 Guide track stopper



#### **INFO**

Pay attention to the profile assessment.

## Installing the guide track stopper, diagram A


1. Insert the stopper [1] and, if required, packers [2] into the guide track.

X = profile-related

Screw down loosely with one screw [3] but so that it is not yet secure.

Check the stopper position and reposition if necessary.

Fasten the stopper with three screws (first [3], then [4]).




## Installing the guide track stopper, diagram C

⇒ Second opening sash is on the bench: mark the position of the roller outer edge of the control unit on the espagnolette side [A].

1. Close the second opening sash.

Transfer the marking for the "position of the roller outer edge of the control unit" from the sash to the frame and move it 82 mm towards the espagnolette side [B].






2. Insert the stopper [1] and, if required, packers [2] into the guide track.

Move the stopper up to the marking [B].

Screw down loosely with one screw [3] but so that it is not yet secure.

Check the stopper position and reposition if necessary.

Fasten the stopper with three screws (first [3], then [4]).



## 9.6.9 Notes on final assembly



## **DANGER**

# Risk of death caused by excessive bending of the running profile.

Incorrect installation of the sash in an element that bends by  $\geq 3$  mm may cause the sash to fall out.

1. Underlay the element so that it bends by < 3 mm.



## INFO

In order to ensure the proper functioning and security of the element, the bending of the frame must not exceed 3 mm.




#### **INFO**

Up to 250 kg: place pressure-proof packers under the threshold every 300 mm across its entire area (see figure).

From 250 kg: place pressure-proof packers under the threshold along its entire length.

[1] Packer





≤300

# 10 Installation drawings


## 10.1 Explanation

The following markings are used in the installation drawings to emphasise references and other elements:

Marking	Meaning	
2.Stabilisationseinheit ab FFB >2110	Second stabilisation unit from sash rebate width > 2110 mm	
4.Steuereinheit ab FFB >2110	Fourth control unit from sash rebate width > 2110 mm	
aktiv	First opening	
Ansicht von innen	View from inside	
Ausfuehrung	Version	
aussen laufend	Running outward	
Beschlagteile links	Hardware components, left	
Beschlagteile rechts	Hardware components, right	
FFB	Sash rebate width	
FehlbedSchliessstueck	Striker to prevent incorrect operation	
FehlbedSchliessstueck RC2	SEC striker to prevent incorrect operation	
FFH	Sash rebate height	
Garnitur-Positionierung	Set positioning	
Holz	Timber	
Holz einfräsbar	Timber, can be routed in	
Holz und Kunststoff aufschraubbar	Timber and PVC, screw-on	
innen laufend	Running inward	
Kunststoff	PVC	
min	Minimum	
max	Maximum	
passiv	Second opening	
Puffer	Stop	
RC 2 / RC 2 N	RC 2 / RC 2 N	
Rueckschiebesicherung	Anti-pushback function	
Schaltfolgeregelung	Operating sequence control	
Schema A	Diagram A	
Schema A'	Diagram A'	
Schema C	Diagram C	
Schema C'	Diagram C'	
Schliessstueck RC2	RC 2 striker	
Schliessteile	Locking components	
Schliessteile Mittelbruch	Locking components on the mullion	
Standard	Standard	
Standardausfuehrung	Standard version	




## 10.2 Diagram A, K, A', K'




IMO\_559\_EN\_v1 · 05 / 2022 · **155** 

## 10.3 Diagram A, K | RC 2 / RC 2 N | PVC





## 10.4 Diagram C, C'



IMO\_559\_EN\_v1 · 05 / 2022 · **157** 

## 11 Adjustment



#### INFO

Roto hardware components may only be adjusted by authorised professionals when the element is installed.

## 11.1 Striker



#### **INFO**

Roto hardware components may only be adjusted by authorised qualified personnel.

#### Lateral adjustment


- 1. Close the window sash (handle position open).
- 2. Adjust the striker [1] using two threaded pins [2] in the fastening plate.

Tool: size 2.5 hex key.



#### **INFO**

The striker features variable height adjustment, which permits an installation tolerance of ±3 mm for the locking cam.




## 11.2 MUL locking cam / pin for anti-pushback function – adjustable




## **INFO**

Roto hardware components may only be adjusted by authorised qualified personnel.

## **Gasket compression adjustment**




Initial position









## 11.3 Roller unit



#### **INFO**

Roto hardware components may only be adjusted by authorised qualified personnel.

## Height adjustment


- 1. Open the window sash in the sliding position.
- 2. Adjust the roller unit using the screw.
- Height adjustment +3 mm: tighten the screw clockwise.
- Height adjustment -1 mm: loosen the screw anticlockwise.

Tool: size 4 hex key



## **INFO**

The screw has a defined final position. If you start to feel resistance, stop turning the screw.



## 12 Operation

## 12.1 Operating information

The windows and balcony doors are operated using a handle.

The following symbols illustrate the different handle positions and the resultant sash positions of the windows and balcony doors.

## 12.1.1 Roto Patio Inowa



#### **ATTENTION**

## Risk of being accidentally locked out.

If the sash is in the sliding position and closes, the sash can engage and then be impossible to reopen from the outside.

- Secure the sash against accidentally engaging when in the sliding position.
- Ensure that access is possible if necessary.

Handle position	Sash position	Meaning
		Sash in closed position.
	-	Sash in open sliding position.
	-	Sash in closed sliding position.

## 12.2 Fault assistance

Fault	Cause	Corrective action	To be carried out by
Handle is difficult to turn.	Frame components have not been greased.	Grease the frame components.	
	Handle is damaged.	Replace the handle.	
	Handle screwed into place too tightly.	Undo the screw fixing slightly.	
	Sash components with slanting screws.	Screw the sash components in straight.	
	Sash components are damaged.	Replace the sash components.	
	Incorrect striker positions.	Adapt the striker positions.	
Handle cannot be turned 180°.	Sash components hinged or installed incorrectly.	Check the setting in the turn position (potentially rehang – start from the T&T espagnolette).	
Locking cams brush against the striker.	Sash components hinged or installed incorrectly.	Check the setting in the turn position (potentially rehang – start from the T&T espagnolette).	
	Incorrect striker positions.	Adapt the striker positions.	

- $\square$  = May be carried out by a specialist company or the end user
- = **Must** be carried out by a specialist company





## 13 Maintenance



#### **CAUTION**

#### Performing maintenance work incorrectly can lead to injuries.

Performing maintenance incorrectly can lead to injuries.

- Ensure that there is sufficient space for installation before starting work.
- Ensure that the installation site is clean and tidy.
- Always have hardware adjustment and replacement work performed by a specialist company.
- ▶ Secure the sash against unintentionally opening or closing.
- Do not unhinge the sash for maintenance.



#### **ATTENTION**

#### Incorrect or improper testing may cause property damage.

Incorrect or improper testing of the hardware may cause the element to malfunction.

- Have the hardware checked by a specialist company when installed.
- If defects need to be remedied, have the element unhinged and remounted by a specialist company.



#### **INFO**

The manufacturer must draw the attention of builders and end consumers to these maintenance instructions.

Roto Frank Fenster- und Türtechnologie GmbH recommends the manufacturer conclude a maintenance agreement with their end users.

No legal claims can be derived from the following recommendations; their application is to be based on the specific individual case.

	Responsibility		
Maintenance interval		→ from page 161	
Cleaning		→ from page 162	
Clean hardware			
Care		→ from page 162	
Lubricate movable parts			
Lubricate locking points			
Performance test		→ from page 163	
Check that hardware components are fitted securely			
Inspect hardware components for wear			
Check that movable parts work properly			
Check that locking points work properly			
Check ease of movement	•		
Repair		→ from page 164	
Retighten screws			
Replace damaged components			

- $\square$  = May be carried out by a specialist company or the end user
- = Must be carried out by a specialist company

#### 13.1 Maintenance intervals



#### **ATTENTION**

#### Failure to adhere to maintenance intervals may cause property damage.

The maintenance interval for all tasks relating to the hardware components is **annually** at the least. In hospitals, schools and hotels, the maintenance interval is **six-monthly**.

Regular maintenance is necessary in order to maintain the proper and smooth-running operation of the hardware and to prevent premature wear or even defects.

Determine and adhere to the appropriate maintenance interval in accordance with the ambient conditions.

Subject to change. Roto Patio Inowa | 400 IMO\_559\_EN\_v1 · 05 / 2022 · **161** 

## 13.2 Cleaning



#### **ATTENTION**

#### Using incorrect cleaning agents and sealing compounds may cause property damage.

Cleaning agents and sealing compounds may damage the surfaces of components and gaskets.

- ▶ Do not use aggressive or flammable liquids, acidic cleaners or abrasive cleaners.
- Only use mild, pH-neutral cleaning agents that have been diluted.
- ▶ Apply a thin protective film to the components, for example using a cloth soaked in oil.
- Avoid aggressive vapours (e.g. produced by formic acid, acetic acid, ammonia, amine compounds, ammonia compounds, aldehyde, carbolic acid, chlorine, tannic acid) around the element.
- ▶ Do not use any acetic acid-crosslinking or acid-crosslinking sealing compounds or those with the aforementioned constituents as both direct contact with the sealing compound and its fumes can corrode the surface of the components.

#### Cleaning the hardware

- ▶ Clean deposits and contaminants off the hardware using a soft cloth.
- ▶ Lubricate movable parts and locking points after cleaning. → 13.3 "Care" from page 162
- Apply a thin protective film to the hardware, for example using a cloth soaked in oil.

#### 13.3 Care



#### **ATTENTION**

#### Using incorrect lubricants may cause property damage.

Substandard lubricants can prevent the hardware from working properly.

- Use high-quality lubricants.
- ▶ Only use resin-free and acid-free lubricants.
- Use appropriate lubricant in more challenging climatic conditions. Note the manufacturer specifications.



#### **ATTENTION**

#### Cleaning agents and lubricants may pollute the environment.

Leaking or excess cleaning agents and lubricants may pollute the environment.

- ▶ Remove any leaking or excess cleaning agents and lubricants.
- Dispose of cleaning agents and lubricants separately and properly.
- Observe the applicable directives and national laws.

Ease of movement can be improved by lubricating or adjusting the hardware. All functional hardware components must be lubricated on a regular basis.

### **Recommended lubricants**

Roto NX / NT grease




## INFO

The figure displays the positioning of potential lubrication points. The figure does not necessarily match the installed hardware. The quantity of lubrication points varies depending on the size and design of the element.



## 13.3.1 Roto Patio Inowa



- [1] Lubricant
- [2] Grease

## 13.4 Performance test



#### **WARNING**

## Improper repair work may pose a risk of death!

Improper maintenance may prevent the element from working properly and make it less safe to use.

Always have repairs performed by a specialist company.

#### Check for proper operation:

- Inspect hardware components for damage, deformation and a firm fit.
- Check that windows or balcony doors run smoothly by opening and closing them.
- Check the window or balcony door gaskets for elasticity and fit.
- Check closed windows or balcony doors to ensure that they are leakproof.



Locking and unlocking torque max. 10 Nm. The test can be performed using a torque wrench.

Have malfunctions remedied by a specialist company.

#### 13.5 Repair



#### WARNING

#### Improper repair work may pose a risk of death!

Improper maintenance may prevent the element from working properly and make it less safe to use.

Always have repairs performed by a specialist company.



#### **ATTENTION**

## Improper screw fixings may cause property damage.

Loose or faulty screws can prevent the hardware from working properly.

- Check that the individual screws are secure and seated correctly.
- ▶ Tighten or replace loose or faulty screws.
- Use only the suggested screws.

Repair work includes replacing and repairing components and is only necessary if components have become damaged after wear or as a result of external circumstances. The hardware must be secured reliably in order to ensure that the element works properly and is safe to use.

The following tasks must only be performed by a specialist company:

- All adjustment work on the hardware,
- Replacing hardware or hardware components,
- Installing and removing windows, doors or balcony doors

The specialist company must observe the following:

- Perform the necessary repair work properly, according to generally recognised engineering practice and in accordance with the applicable regulations.
- Do not perform makeshift repairs on worn or damaged components.
- Only use original or approved spare parts for repairs.



## 14 Dismantling



#### **WARNING**

## Improper dismantling may pose a risk of death!

The sash may fall during dismantling.

- Secure the sash to prevent it from falling, e.g. by using two people.
- Always have dismantling work performed by a specialist company.



#### **CAUTION**

## Physical strain may cause injury and damage to health.

Carrying and lifting heavy loads for extended periods leads to physical injury in the long term.

When carrying or lifting loads, maintain an ergonomically correct posture. The maximum permissible load is 25 kg for men and 10 kg for women.




#### **INFO**

Unless otherwise stated, dismantling is performed in reverse order to installation.

## 14.1 Unhinging the sash

#### Version with split guide track

1. Remove the guide track in the fixed glazing area.




2. Move the handle to the open sliding position




IMO\_559\_EN\_v1 · 05 / 2022 · **165** 

3. Push the sash onto the roller track in front of the fixed glazing area in a controlled manner until the control units are exposed.



4. Remove the sash parallel to the frame.




## Version with continuous guide track

1. Move the handle to the open sliding position





2. Lift the sash and tilt it outwards at the bottom. Lower the sash in a controlled manner until the control units are exposed.



3. Remove the sash parallel to the frame.

## 14.2 Hardware components

## Removing hardware components

- 1. Undo all screw connections.
- 2. Remove the hardware components.
- 3. Dispose of the hardware components properly.



## 15 Transport

## 15.1 Transporting elements and hardware



#### **DANGER**

#### Improper transport poses a risk of death!

Improper procedures for transporting, loading or unloading elements may cause serious injuries and glass breakage as a result of the elements swinging open, falling or becoming overloaded.

- Note the applicable accident prevention regulations.
- Note force application points and reaction forces.
- Prevent the sash from opening uncontrollably.
- Avoid jerky movements.
- Use suitable transportation means and protective devices.
- Watch out for protruding components.
- Transport heavy loads with two people and use suitable transportation means (such as an industrial truck).



#### **CAUTION**

#### Trapped limbs may result in injuries.

The transported goods can skid, open, close or fall during transportation tasks. This can result in limbs being trapped and seriously injured.

- Never reach near the scissor stays.
- Close the sash after installation and secure it in place for transport.
- Wear safety gloves and protective footwear.



#### **CAUTION**

# Physical strain may cause injury and damage to health.

Carrying and lifting heavy loads for extended periods leads to physical injury in the long term.

When carrying or lifting loads, maintain an ergonomically correct posture. The maximum permissible load is 25 kg for men and 10 kg for women.

Hardware is supplied to the specialist company as complete sets. The components are packaged accordingly for each scope of delivery. The instructions for safely transporting the hardware are described below.

Observe the following basic instructions when transporting hardware:

- Transport larger scopes of delivery using appropriate transportation means (such as industrial trucks).
- Note the transport weight in order to select appropriate transportation means
- Ensure that the transport process is careful and appropriate for the material and that components are protected against dirt during transport.
- Immediately check the delivery for completeness and transport damage on receipt.







#### **INFO**

Submit a complaint about any defects as soon as they are identified. Claims for damages may only be made within the reclamation period.

Use the following transportation means for support when transporting, loading and unloading larger scopes of delivery:

- Industrial trucks, e.g. forklifts, telescopic handlers, pallet trucks
- Lifting equipment, e.g. transport nets, carry straps, round slings
- Protective devices, e.g. edge protection, spacer blocks



## **INFO**

Industrial trucks and lifting devices may only be operated by qualified persons.



#### **INFO**

Lifting equipment and protective devices may only be used if they are in full working order.

## 15.2 Storing the hardware

Store all hardware components as follows until they are installed:

- Dry and protected
- On a level surface
- Protected against sunlight



## 16 Disposal



#### **ATTENTION**

## Incorrect disposal may pollute the environment.

Pieces of hardware are raw materials.

 Dispose of hardware for environmentally friendly material reutilisation as mixed scrap.

## 16.1 Disposing of packaging

The hardware is supplied as complete sets together with the packaging. Once unpacked, the installation company or builder is responsible for disposing of the packaging properly. The packaging materials are produced in accordance with current environmental protection standards. The materials can be recycled separately.

Follow the basic instructions below for the proper disposal of packaging:

- Do not dispose of packaging in household waste.
- ▶ Hand over packaging at local waste collection points or recycling centres.
- Observe the national regulations on the disposal of recyclable materials.
- Contact the local authorities if necessary.

## 16.2 Disposing of hardware

Once the hardware is finished with, the end user or builder is responsible for properly disposing of the windows, doors or balcony doors and the hardware, including any accessories. Hardware is produced in accordance with current environmental protection standards. The materials can be recycled separately.

Follow the basic instructions below for the proper disposal of hardware:

- Observe the information and specifications for disposal contained in the other applicable documents.
- Separate hardware components from windows, doors or balcony doors.
- Do not dispose of hardware in household waste.
- ► Hand over hardware at local waste collection points or recycling centres.
- Observe the national regulations on the disposal of recyclable materials.
- Contact the local authorities if necessary.





## Roto Frank Fenster- und Türtechnologie GmbH

Wilhelm-Frank-Platz 1 70771 Leinfelden-Echterdingen Germany

Phone +49 (0) 711 7598 0 Fax +49 (0) 711 7598 253 info@roto-frank.com

www.roto-frank.com

## From a single source: Optimum hardware systems to meet all challenges

Roto Window | Hardware systems for windows and balcony doors
Roto Sliding | Hardware systems for large sliding windows and doors
Roto Door | Matching hardware technology everything about doors
Roto Equipment | Additional technology for windows and doors